

Hybrid recorder
HR-700
(Dot printing type)
Instruction manual

Shinko
North America Ltd.

Web Site: www.shinkona.com

25 Whitefriars Drive
Toronto, Ontario, Canada M3A 2L2
TEL: 416 444-0817
FAX: 416 444-2361
TOLL FREE: 1 888-4SHINKO

Email: sales@shinkona.com

4. WIRING

4.1 Terminal arrangement and power wiring

4.1.1 Terminal arrangement




Fig. 4.1 Terminal Layout (Rear view)

4.1.2 Power Wiring



WARNING

- ① In order to prevent an electric shock, be sure to provide protective grounding prior to the power supply to the instrument.
- ② Do not cut a protective grounding conductor or disconnect protective grounding.
- ③ Make sure that the supply voltage for the instrument conforms to the voltage of the supply source.
- ④ Attach a transparent protective cover prior to turning on the POWER of the instrument.
- ⑤ Any interruption of the protective conductor inside or outside the instrument or disconnection of the protective grounding terminal is likely to make the instrument dangerous under some fault conditions. Intentional interruption is prohibited.



CAUTION


- ① As an electric wire for the power source, use a 600 V vinyl insulated wire (IEC 227-3) or its equivalent or above.
- ② Attach a round press-fitting terminal with insulated sleeve (for M3.5) to the end of the electric wire.
- ③ Connect a protective grounding (resistance:100 Ω or lower, a minimum diameter of a grounding conductor:1.6mm) to the protective grounding terminal.
- ④ If other instrument shares the protective grounding conductor, there may be an effect caused by noise coming from the grounding conductor. It is recommended not to share it with other instrument.
- ⑤ In order to comply with the requirements of safety standard EN61010, the recorder shall have one of the following as a disconnecting device, fitted within easy reach of the operator, and labeled as the disconnecting device.
 - a. A switch or circuit breaker which complies with the requirements of IEC60947-1, IEC60947-2 and IEC60947-3.
 - b. A separable coupler which can be disconnected without the use of a tool.
 - c. A separable plug, without a locking device, to mate with a socket outlet in the building.
- ⑥ This product has designed to conform to IEC1010-1 installation Category II and pollution degree 2.

4.1.3 Wiring Procedure



CAUTION

The transparent protective cover should surely remove the left and right (both sides) hooks simultaneously. If it removes by turns, there is a possibility that it may be damaged.

- 1) Put your fingers on the left and right (both sides) hooks of the transparent protective cover on the power source terminal block. Pushing them inside, pull out the cover.
- 2) Connect the power source electric wire referring to Fig. 4.2. Connect the protective grounding to the  terminal. Connect the non-grounding side of the power source to "L" terminal. Connect the grounding side to the "N" terminal.
- 3) Put on the transparent protective cover.
- 4) Make sure that protective grounding is properly done.




Fig. 4.2 Power source Terminal block

4.2 Input Wiring



CAUTION

① Precautions for the input electric wire

- See to it that no noise is mixed in input wiring. For input wiring, it is recommended a shielding wire or twisted wire effective for noise be used.
- In the case of thermocouple input, connect a thermocouple wire directly or use a compensating lead wire. It is recommended a shielded input line be used.
- In the case of resistance temperature detector input, dispersion of 3-wire line resistance should be less than the below mentioned values. It is recommended a shielded input line be used.
For Pt 100, JPt 100 ; 50m Ω max.
- When it is likely to be affected by induction noise, particularly when wiring near the high-frequency power source, it is recommended a shielded twisted wire be used.
- Attach a round press-fitting terminal with insulated sleeve (for M3.5) to the end of the electric wire.

② Precautions for wiring

- The wiring between the instrument and measurement point should be kept away from the power circuit (25V or higher circuit or DO circuit).
- Short-circuit unused input terminals. (Short-circuit between "+" and "—" in the case of mV, V, or thermocouple input, and short-circuit among A, B, and B in the case of resistance temperature detector input.)
- Be sure to ground the shield of connecting wire.

4.2.1 Wiring Procedure



CAUTION

The transparent protective cover should surely remove the left and right (both sides) hooks simultaneously. If it removes by turns, there is a possibility that it may be damaged.

- 1) Put your fingers on the left and right (both sides) hooks of the transparent protective cover on the input terminal block. Pushing them inside, put out the cover.
- 2) Wire the input lines referring to Fig. 4.3(Page 18), Fig. 4.4 and Fig. 4.5.(Page 19)
- 3) Put on the transparent protective cover.




Fig. 4.3 Input Wiring (For mV, V and Thermocouple inputs)




Fig. 4.4 Input Wiring (For Resistance temperature detector)




Fig. 4.5 Input Wiring (For mA input)



CAUTION

- ① Attach the shunt resistor to the input terminal block of the instrument.
- ② A shunt resistor influences input accuracy. Use the following recommended resistor.
Resistance: 250 Ω , Rated power: 1/4W, Tolerance: $\pm 0.1\%$ max.
Temperature coefficient: $\pm 50\text{ppm}$ max.

4.3 DI function/Alarm Output Wiring (Option)



WARNING

- ① Be sure to wire after turning off the POWER.
- ② When the power source has been connected to the Alarm output, turn off that power source.
- ③ When a hazardous voltage is supplied to alarm terminal:
 - a) Never touch terminals preventing from electric shock.
 - b) Attach covers to terminals.
 - c) Wires should be double shielded.
 - d) Adopts round pressure terminal connectors with insulation cover for wire, preventing from lose connection.



CAUTION

Precautions for Wiring the DI function

- ① DI function input has the built-in drive power source. Do not apply a voltage to a DI function input terminal from the outside.
- ② A DI function input contact capacity should be a withstanding voltage of 50Vdc, 16mA or more, ON resistance of 20 Ω max.(Wiring resistance included).
- ③ Do not use unused terminals as relay terminals.

Precautions for Wiring the Alarm Output

- ① An alarm output contact capacity is as follows :

| | |
|----------|--|
| 250Vac : | 3A at maximum (Resistive load) |
| 30Vdc : | 3A at maximum (Resistive load) |
| 125Vdc : | 0.5A at maximum (Resistive load) |
| | 0.1A at maximum L/R= 7ms at maximum (Inductive load) |
- ② Attach an anti-surge protective circuit (surge absorbers, etc.) to an output terminal, when required.
- ③ Attach a round press-fitting terminal with insulated sleeve (for M3.5) to the end of an electric wire.
- ④ Keep alarm output wiring away from input wiring.
- ⑤ Do not use unused terminals as relay terminals.

4.3.1 DI function/Alarm Output Wiring Example




Fig. 4.6 DI function Wiring Example




Fig. 4.7 Alarm Output Wiring Example



4.3.2 Alarm Output Wiring Procedure

4.3.3 DI function Wiring Procedure

Fig. 4.9 DI function Wiring

DI1
DI2
DI3
DI.COM
(COMMON for DI1 to DI3)

4.4 Communication Wiring



CAUTION

Precautions for the communication wiring

- ① See to it that no noise is mixed in communication wiring. For communication wiring, it is recommended a shielding wire effective for noise be used.
- ② When it is likely to be affected by induction noise, particularly when wiring near the high-frequency power source, it is recommended a shielded twisted wire be used.
- ③ Attach a round press-fitting terminal with insulated sleeve (for M3.5) to the end of the electric wire.
- ④ Be sure to ground the shield of a connecting wire.

4.4.1 RS-232C Wiring

Wire RS-232C referring to Fig.4.10.




Fig. 4.10 RS-232C Wiring

[Note]

Cable length is a maximum of 15m.

4.4.2 RS-485 Wiring

Wire RS-485 referring to Fig.4.11.




Fig. 4.11 RS-485 Wiring

[Note]




- ① Be sure to attach terminating resistance (R_t 200 Ω) to a host computer side.
- ② Connection is a maximum of 32 sets including a host computer.
- ③ Cable length is a maximum of 1.2 km.
- ④ Use the UL20620-SB (M) cable made by HITACHI CABLE LTD. or equivalent.


For safety using

Thank you for purchasing our HR-706 type Hybrid Recorder.

In order to use this instrument all of its functions effectively and correctly, read and understand this instruction manual thoroughly before using the instrument.

The symbols below are used on this instrument for the cautioning information.

| Symbols used on the instrument | |
|---|---|
|  | This shows "Caution for handling". This symbol is used on the parts need to refer to the instruction manual for protecting human body and the instrument. |
|  | This shows "Protective grounding". Be sure to provide protective grounding prior to the operation of this instrument. |
|  | This shows "Risk of electric shock". This symbol is used on the parts, which has a risk of electric shock. |

| Be sure to observe the following warnings/cautions and those written in this manual in order to secure safety when using this instrument. | |
|---|---|
|  WARNING | |
| General | In order to prevent electric shock; be sure to disconnect this instrument from the main power source when wiring it. |
| Protective Grounding | <ol style="list-style-type: none">(1) In order to prevent an electric shock; be sure to provide protective grounding prior to turning on this instrument.(2) Do not cut a protective grounding conductor or disconnect protective grounding. |
| Power Source | <ol style="list-style-type: none">(1) Make sure that the supply voltage for this instrument conforms to the voltage of the supply source.(2) Attach a protective cover prior to turning on this instrument. |
| Working Environment | Do not operate this instrument in the environment where it is exposed to a combustible/explosive/corrosive gas or water/steam. |
| Input and Output Wiring | Provide input and output wiring after turning off the power. |



CAUTION

Input and Output Wiring

Do not use unused terminals for other purposes such as relaying, etc.

Transportation

Do not touch the switches, etc. inside this instrument. Also, do not replace the main unit or printed circuit boards. When this is neglected, we cannot guarantee functioning of the instrument. Contact our dealer where you purchased the instrument, or our sales representative.

Inside of Instrument

When transporting this instrument or the equipment with this instrument incorporated in it, take measures to prevent opening the door and falling out the inner module.

[Note]

Instruction Manual

- (1) Deliver this instruction manual to an end user.
- (2) Prior to handling this instrument, be sure to read this manual.
- (3) If you have any questions on this manual or find any errors or omissions in this manual, contact our sales representative.
- (4) After reading this manual, keep it carefully near the instrument.
- (5) When the manual is lost or stained, contact our sales representative.
- (6) It is prohibited to copy or reproduce this manual without our permission.

Installation

- (1) When installing this instrument, put on a protective gear such as safety shoes, helmet, etc. for your safety.
- (2) Do not put your foot on the installed instrument or get on it, because it is dangerous.

Maintenance

Only our servicemen or people authorized by Shinko are allowed to remove and take the inner module, the main unit and PRINTed circuit boards apart.

Disposal

- (1) Dispose the replaced batteries in a correct way.
- (2) Do not incinerate plastics of maintenance parts and replacement parts. A harmful gas may be produced.

Cleaning

- (1) Use dry cloth to clean the surface of this instrument.
- (2) Do not use any organic solvent.
- (3) Clean the instrument after the power is turned off.

Revisions

This instruction manual is subject to change without prior notice.

Using procedure for this manual

1.Using procedure



This instruction manual consists of “For safety using”, “Contents” and “Chapter 1 to Chapter 11” as below.
Read the corresponding sections for your purpose to use this instrument.

| Chapter and TITLE | For purchase and install | For initial setting and change setting | For daily operation | For using communication | For maintenance and trouble-shooting |
|-------------------------------|--------------------------|--|---------------------|-------------------------|--------------------------------------|
| For safety using (page 1) | ◎ | ◎ | ◎ | ◎ | ◎ |
| 1. INTRODUCTION | ◎ | | | | |
| 2. CONSTRUCTION | ○ | ○ | ○ | | ○ |
| 3. INSTALLATION | ◎ | | ○ | | |
| 4. WIRING | ◎ | ○ | ○ | ○ | ○ |
| 5. PREPARATIONS FOR OPERATION | | ○ | ◎ | | |
| 6. OPERATION | | ○ | ◎ | | |
| 7. DEVICE SETTING | | ◎ | | ○ | ○ |
| 8.COMMUNICATIONS | | | | ◎ | |
| 9. MAINTENANCE | | | | | ◎ |
| 10. TROUBLESHOOTING | | ○ | | | ◎ |
| 11. SPECIFICATIONS | ○ | ○ | | | ○ |

◎ : Be absolutely certain to read this.

○ : Be certain to read this if you need.

The symbols below are used on the warning and cautioning information in this manual.

| Symbols used in this manual | |
|--|---|
|  WARNING | Failure to observe this information could result in death or injury. Be absolutely certain to read this. |
|  CAUTION | Failure to observe this information could damage the instrument. Be certain to read it. |
| [Note] | This is cautionary information for correct use of the instrument. Be certain to read it. |
| [Reference] | This is information to help you use the functions of this instrument more effectively. |

2.Guid of Instruction manual

The instruction manuals of this instrument are as the table below.

| | Name | Part No. | Outline |
|-----------------|---|----------|---|
| This → manua | 1 HR-700 Hybrid Recorder (Multipoint type) instruction manual | No.HR71E | Explanation for installing, wiring, standard operation. And setting or operation for using this instrument. |
| | 2 HR-700 Hybrid Recorder Communication Command instruction manual | No.HR7CE | Explanation for reading and writing data of the recorder by communication function. |

CONTENTS

| | | | |
|--|-----------|--|-----------|
| 1. INTRODUCTION | 6 | 7. DEVICE SETTING | 40 |
| 1.1 Checking the Accessories | 6 | 7.1 Setting the Setup Mode | 40 |
| 1.2 Checking the Type and Specifications | 7 | 7.1.1 Setting the Range | 43 |
| 1.3 Temporary Storage | 8 | (1) Setting method | 43 |
| 1.4 Indication Card | 8 | (2) HoLb (Current/Voltage), tC (Thermocouple), rtd (Resistance Temperature Detector) | 44 |
| 2. CONSTRUCTION | 9 | (3) SCALE (Scaling) | 46 |
| 2.1 Appearance | 9 | (4) SqRt (Square Root) | 48 |
| 2.2 Display Screen and Operation Keys | 10 | (5) dECAd (Decade) | 50 |
| 2.2.1 Display Screen | 10 | (6) dELt (Difference), Si CA (Sum), AEAr (Average) | 52 |
| 2.2.2 Operation Keys | 11 | (7) SkP (Skip) | 53 |
| 3. INSTALLATION | 12 | 7.1.2 Setting the Alarm | 54 |
| 3.1 External dimensions and panel cutout | 12 | 7.1.3 Setting the Unit | 56 |
| 3.2 Mounting to the Panel | 13 | (1) Character Code Table | 57 |
| 3.2.1 Procedure for Mounting to the Panel | 13 | 7.1.4 Setting the Chart feed Speed | 58 |
| 3.2.2 Mounting to the Panel in compliance with the IP65 | 14 | 7.1.5 Setting the Date and Time | 59 |
| 4. WIRING | 15 | 7.1.6 Copying the Setting Data | 60 |
| 4.1 Terminal Layout and Power Wiring | 15 | 7.1.7 Setting Other Functions | 61 |
| 4.1.1 Terminal Layout | 15 | (1) trEnd (Printing Cycle) | 62 |
| 4.1.2 Power Wiring | 15 | (2) Zone (Zone Recording) | 62 |
| 4.1.3 Wiring Procedure | 16 | (3) PARt (Partial Compression/Expansion) | 63 |
| 4.2 Input Wiring | 17 | (4) Prnt (Digital Print) | 64 |
| 4.2.1 Wiring Procedure | 18 | (5) tAG (Tag) | 65 |
| 4.3 DI function/Alarm Output Wiring (Option) | 20 | (6) CArE (Comment Words) | 66 |
| 4.3.1 DI function/Alarm Output Wiring Example | 20 | 7.2 Setting the Engineering Mode | 67 |
| 4.3.2 Alarm Output Wiring Procedure | 21 | 7.2.1 Alarm Hysteresis | 70 |
| 4.3.3 DI function Wiring Procedure | 21 | 7.2.2 Burnout ON/OFF | 70 |
| 4.4 Communication Wiring | 22 | 7.2.3 Channel Offset | 70 |
| 4.4.1 RS-232C Wiring | 22 | 7.2.4 Reference Junction Compensation | 71 |
| 4.4.2 RS-485 Wiring | 22 | 7.2.5 Changing the Printing Color | 72 |
| 5. PREPARATIONS FOR OPERATION | 23 | 7.2.6 Settings Related to Recording | 73 |
| 5.1 Setting the Chart Paper | 23 | (1) Recording start/stop trigger setting | 73 |
| 5.2 Setting the Ribbon Cassette | 29 | (2) Tag/channel print selection | 73 |
| 6. RUNNING | 31 | (3) Alarm print ON/OFF | 74 |
| 6.1 Running | 31 | (4) Logging print ON/OFF | 74 |
| 6.1.1 Status after Initial Screen | 31 | (5) Scale print ON/OFF | 75 |
| 6.2 Recording | 32 | (6) Logging print Synchronous/Asynchronous | 75 |
| 6.2.1 Recording Colors | 32 | 7.2.7 Setting the Communication Function | 76 |
| 6.3 How to Record | 32 | 7.2.8 Initializing the Setup Data | 76 |
| 6.3.1 Starting/Stopping Recording Operation | 32 | 7.2.9 DI functions | 77 |
| 6.3.2 Feed the Chart Paper | 32 | 7.2.10 Temperature Unit | 77 |
| 6.3.3 Print Sample | 33 | 7.2.11 Point Calibration | 78 |
| 6.4 Digital Print | 34 | 7.2.12 Data Calibration | 79 |
| 6.4.1 Manual Print | 34 | 7.3 Terminating the Engineering Mode | 81 |
| 6.4.2 List Print | 35 | | |
| 6.4.3 Engineering List Print | 37 | | |
| 6.5 Changing the Display | 39 | | |
| 6.5.1 Auto Display < Auto > | 39 | | |
| 6.5.2 Manual Display < MAN > | 39 | | |
| 6.5.3 Date Display < date > | 39 | | |
| 6.5.4 Time Display < ti ME > | 39 | | |
| 6.5.5 Display Off < OFF > | 39 | | |

| | | | |
|--|-----------|---|------------|
| 8. COMMUNICATIONS..... | 82 | 10. TROUBLESHOOTING..... | 94 |
| 8.1 General Description..... | 82 | 10.1 Troubleshooting..... | 94 |
| 8.1.1 General Description of Functions | 82 | 10.1.1 Trouble Items..... | 94 |
| 8.1.2 Transmission Specifications..... | 82 | 10.1.2 When the Recorder Dose not Work at All | 94 |
| 8.1.3 Data Structure..... | 82 | 10.1.3 When there is a Big Error..... | 95 |
| 8.2 Opening/Closing the Link..... | 83 | 10.1.4 When the Trend Recording is Deflected | 95 |
| 8.2.1 Open Command..... | 83 | 10.1.5 When Nothing is Recorded..... | 96 |
| 8.2.2 Close Command..... | 83 | 10.1.6 When Recording is Faint | 96 |
| 8.3 Outputting the Process Variable | 84 | 10.1.7 When the Chart Paper is not fed at All | 97 |
| 8.3.1 Specifying the Process Variable Output | 84 | 10.1.8 When the Chart Paper is not fed Properly | 97 |
| 8.3.2 Updating the Data..... | 84 | 10.2 Self Diagnostics Function (ERROR) | 98 |
| 8.3.3 Specifying the Process Variable Data Output Order (At BINARY Mode Output) | 84 | 10.2.1 Self Diagnostic Items | 98 |
| 8.3.4 Outputting the Data | 84 | 10.2.2 Error Display | 99 |
| 8.3.5 Process Variable Transmission Format (ASCII)..... | 85 | 11. SPECIFICATIONS | 100 |
| 8.3.6 Process Variable Transmission Format (BINARY) | 86 | 11.1 Common Specifications | 100 |
| 8.4 Outputting the Unit and Decimal Point Position Data | 87 | 11.1.1 Input Signal | 100 |
| 8.4.1 Specifying the Unit and Decimal Point Position Data Output | 87 | 11.1.2 Performance and Characteristics | 100 |
| 8.4.2 Updating the Data..... | 87 | 11.1.3 Structure..... | 101 |
| 8.4.3 Outputting the Data | 87 | 11.1.4 Power Source | 101 |
| 8.4.4 Data Format..... | 87 | 11.1.5 Normal Operating Conditions | 101 |
| 8.5 Outputting the Status..... | 88 | 11.1.6 Alarm Output (Optional : LH6) | 102 |
| 8.5.1 Status Output Command | 88 | 11.1.7 Safety Standard and EMI Standard..... | 102 |
| 8.5.2 Status Output..... | 88 | 11.1.8 DI Function (Option : RE6)..... | 102 |
| 8.6 Data Reception Example | 89 | 11.1.9 Paper-empty Detecting Function (Option : FL) | 102 |
| 9. MAINTENANCE..... | 90 | 11.2 Standard Specifications | 103 |
| 9.1 Inspection..... | 90 | 11.2.1 Measurement Range..... | 103 |
| 9.2 Cleaning..... | 90 | 11.2.2 The Accuracy at the Computation | 106 |
| 9.3 Replacing Consumables | 91 | (1) Scaling..... | 106 |
| 9.4 Adjust Dot Printing Position (Point Calibration)..... | 91 | (2) Square root computation..... | 106 |
| 9.5 Calibration (Data Calibration)..... | 91 | (3) Decade..... | 107 |
| (1) Calibration of Voltage..... | 92 | (4) Difference, Sum, and Average..... | 107 |
| (2) Calibration of Resistance temperature detector | 92 | 11.2.3 Individual Specifications | 108 |
| (3) Calibration of Reference Junction Compensation..... | 93 | 11.2.4 Standard Functions | 109 |
| | | 11.3 Standard Setting Functions..... | 110 |
| | | 11.3.1 Standard Setting Functions..... | 110 |
| | | 11.4 Optional Functions | 110 |
| | | 11.4.1 Remote Function of DI | 110 |
| | | 11.4.2 Alarm Board..... | 110 |
| | | 11.4.3 Communication unit..... | 110 |

1. INTRODUCTION


1.1 Checking the Accessories

Upon delivery of this instrument, unpack and check its accessories and appearance.


If there are any missing accessories or damage on the appearance, contact our dealer where you purchased the instrument, or our sales representative.

Following accessories should be attached.


①Chart paper




②Ribbon cassette



③Mounting bracket



④Instruction manual



⑤Packing




Fig. 1.1 Accessories

Table 1.1 List of Accessories

| No. | Part Name | Type | Quantity | Remarks |
|-----|--------------------|-----------------|----------|------------------------|
| 1 | Chart paper | H-10100 | 1 | 100 equal divisions |
| 2 | Ribbon Cassette | WPSR188A000001A | 1 | |
| 3 | Mounting bracket | H4A14175 | 2 | Panel mounting bracket |
| 4 | Instruction manual | HR71E | 1 | This manual |
| 5 | Packing | H4H14900 | 1 | For IP65 |

[Note]

The ribbon cassette has been set in the instrument when this is shipped.

1.2 Checking the Type and Specifications

A nameplate is put on the inside of the instrument. Remove the chart holder and make sure that the nameplate is put in the middle far side of the instrument.

Make sure that this instrument meets your requested specification, seeing the following tables.

Table 1.2 Type

| | | | |
|-----------------|---|----------------------------|---------------------------------|
| HR-706, □□□ | | 144(W) × 144(H) × 150(D)mm | |
| Measuring point | 6 | | 6 points |
| Options | | C5 | Communication function (RS-485) |
| | | RE6 | DI function |
| | | FL | Out of paper detection function |
| | | LH6 | Alarm output function |

1.3 Temporary Storage

Store the instrument in the following environment.

When incorporated in the equipment, store it in the following environment as well.



CAUTION

Storage in a poor environment may damage the appearance, functions, and service life of the instrument.

Storage Environment

- A place with little dust.
- A place free from combustible, explosive, or corrosive gases (SO₂, H₂S, etc.).
- A place free from vibrations or shocks.
- A place free from water or steam or high humidity (95% RH max.).
- A place free from direct sunlight or high temperature (50°C max.).

1.4 Indication Card

An indication card has been affixed to the door upon delivery. Enter a name as required.



CAUTION

Note that if a non-original nameplate is attached, it may damage the door or mounting part.

2. CONSTRUCTION

2.1 Appearance




Fig. 2.1 Appearance

2.2 Display Screen and Operation Keys

2.2.1 Display Screen

The following describes the display screen. Since the channel numbers and data are indicated by a 7-segment LED, alphabets are symbolized to represent them.

For the LED display, see "Symbolized Alphabets for Display" at [Reference] below.




Fig. 2.2 Display

[Reference] Symbolized Alphabets for Display

| | | | | | | | | | | | | | | |
|----------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Display | A | b | C | d | E | F | G | H | h | I | J | K | L | l |
| Alphabet | A | B | C | D | E | F | G | H | h | I | J | K | L | l |
| Display | M | N | O | P | Q | R | S | T | U | V | W | X | Y | Z |
| Alphabet | M | N | O | P | Q | R | S | T | U | V | W | X | Y | Z |

2.2.2 Operation Keys

The following describes the functions of each operation key.

The actual operation keys are represented as shown in the figure below in this manual.




Fig. 2.3 Actual Display and Operation Keys

Table 2.1 Names of Operation Keys and Their Functions

| Key | Name | Function | |
|-----|-------------|---|--|
| | "REC" key | Starts/stops recording. To stop, press the "REC" key for 3 seconds or more. (Puts out the "REC" lamp.) To start, press the "REC" key. (Lights the "REC" lamp.) | |
| | "MENU" key | MENU function | Selects engineering list print and changes the mode to the setting mode. |
| | "ESC" key | ESC function | Exits that menu halfway while selecting a function. |
| | "PRINT" key | PRINT function | Used to perform manual print or list print. |
| | "Δ" key | Δ function | Used to select a setting parameter (numeral or built-in command)(ascending direction). |
| | "FEED" key | FEED function | The chart paper is fed while the key is pressed, and stopped when released. |
| | "▷" key | ▷ function | Used to shift a digit in setting a numeral. |
| | "ENT" key | Used to register a setting parameter (numeral or built-in command) after selecting it, or executing a function. Pressing this key executes the setting. | |

3. INSTALLATION

3.1 External dimensions and panel cutout

Unit: mm




Fig. 3.1 External dimensions and panel cutout



CAUTION

For maintenance and using the instrument safely, it is recommended that spaces larger than the size written in the bracket be secured per unit.

3.2 Mounting to the Panel



WARNING

Do not install the instrument in a place exposed to combustible, explosive, or corrosive gas (SO_2 , H_2S , etc.).



CAUTION

Install the instrument in the following places

- A place without rapid humidity change.
- A place of normal temperature (25°C or so).
- A place exposed to as little mechanical vibrations as possible.
- A place with as little dusts as possible.
- A place affected by the electromagnetic field as little as possible.
- A place not directly exposed to high radiant heat.
- A place where the altitude is up to 2000m.
- Humidity has an effect on the chart paper and ink. Use the instrument in a humidity range of 20 to 80%RH (60%RH is optimum).
- This instrument needs the inside installation.

Mounting to the Panel

- A steel plate not thinner than 1.2mm is recommended as a mounting panel.
- The maximum thickness of the mounting panel is 7mm.

Inclination

- Install the instrument horizontally.
- The instrument should be installed so that its inclination should be 0° at the front and within 30° at the rear.

3.2.1 Procedure for Mounting to the Panel

- 1) Assemble the mounting bracket referring to Fig.3.2.
- 2) Insert this instrument through the front of the panel.
- 3) Hook claws of the mounting bracket at the square holes on the top and bottom surfaces of the case.
- 4) Tighten the screw of the mounting bracket with a screwdriver to attach it to the panel. When the mounting unit does not move back and forth any more, tighten a screw by 180° .




Fig. 3.2 Mounting bracket

[Note]

If it is tightened with an excessive force, the case may be distorted and the mounting bracket may be deformed. An adequate tightening torque is about 0.2 to 0.3 N·m (2~3 kgf·cm).




Fig. 3.3 Mounting to the Panel

3.2.2 Mounting to the Panel in compliance with the IP65

Prior to mounting the instrument to the panel, attach a packing to the position shown in the figure. The rest of the procedure is the same.




Fig. 3.4 Mounting to the Panel (in compliance with the IP65)

5. PREPARATIONS FOR OPERATION

5.1 Setting the Chart Paper

CAUTION

It is recommended our original chart paper be used to ensure proper recording. If the chart paper holder is taken out with recording operation being activated, the ink ribbon may be damaged. To replace the chart paper, be sure to press the “REC” key to stop recording.

(1) Pressing the “REC” key for 3 seconds or more

Stop recording operation. With the power turned on, press the “REC” key for 3 seconds or more.




Fig. 5.1 Pressing the “REC” key

(2) Opening the Door

CAUTION

Maximum angle of the door is 135 degrees when the door is fully open. Do not open the door further, or the hinge will be broken.

Push the door hook to unlock the door. Pull out the door to open it.




Fig. 5.2 Opening the Door

(3) Pulling out the Chart Holder

Put your fingers onto the levers at both sides of the chart holder and pull it out.




Fig. 5.3 Pulling out the Chart Holder

(4) Opening the Chart Cover and Chart Guide

Open the chart guide and the chart cover outward.




Fig. 5.4 Opening the Chart Cover and Chart Guide

(5) Loosening the chart paper

The chart paper may not be proper fed, if it is stuck at perforations. Be sure to loosen the paper.



Fig. 5.5 Loosening the Chart Paper

(6) Setting the Chart Paper into the Storage Chamber

Unfold the 2 sections of chart paper. Holding the printing surface upward, set it in the storage chamber.




Fig. 5.6 Setting the Chart Paper

(7) Aligning the Chart Paper with the Sprocket Drum

Align the holes in the chart paper with the sprocket drum teeth. Set the chart paper along with the sprocket drum. Put the first ply of the chart paper into the chart receiver.




Fig. 5.7 Aligning the Chart Paper with Sprocket Drum (Chart Holder Sectional View)

(8) Closing the Chart Cover and Chart Guide

Close the chart cover and the chart guide in the arrow directions.




Fig. 5.8 Closing the Chart Cover and Chart Guide

(9) Turning the Sprocket Drum Gear

Check paper feed with your hand. Turn the sprocket drum gear to feed out the chart paper.
(It is recommended 4 sections of chart paper be fed out.)




Fig. 5.9 Checking Paper Feed

(10) Putting the Chart Paper Holder

Insert the chart holder horizontally into the case until it is locked.




Fig. 5.10 Putting Back the Chart Holder

(11) Close the Door

Close the door and check a door lock.

(12) Pressing the “FEED” key to Check Paper Feed

Press the “FEED” key on the display keyboard to feed the chart paper.




Fig. 5.11 Pressing the “FEED” key

(13) Pressing the “REC” Key to Restart Operation

5.2 Setting the Ribbon Cassette



CAUTION

If the chart holder is taken out with recording operation being activated, the ink ribbon may be damaged. To replace the ribbon cassette, be sure to press the “REC” key to stop recording. If the ribbon cassette is not set properly, the recording color may change or the ribbon may be damaged.

(1) Pressing the “REC” key for 3 seconds or more

Stops recording. With the power turned on, press the “REC” key for 3 seconds or more.

Once recording stops, the REC lamp goes off. (See Fig. 5.1 on page 23)

(2) Opening the Door

Push the door hook to unlock the door. Pull the door to open it.

(See Fig.5.2 on page 23)



CAUTION

Maximum angle of the door is 135 degrees when the door is fully open. Do not open the door further, or the hinge will be broken.

(3) Pulling out the Ribbon Cassette

Grab the left side of the ribbon cassette. Holding down the ribbon holder, pull out the ribbon cassette to the front.




Fig. 5.12 Taking Out the Ribbon Cassette

(4) Unslacking the Ink Ribbon

Set the new ink ribbon. Turn the knob in the arrow direction to unslack the ink ribbon.




Fig. 5.13 Unslacking the Ink Ribbon

(5) Setting the Ribbon Cassette

Push the ribbon cassette into the ribbon holder until the latch clicks.

When the ribbon feeding shaft does not easily fit in, turn the gear in the direction of an arrow to adjust the position. When this is done, push the ribbon cassette until the latch clicks




Fig. 5.14 Setting the Ribbon Cassette

6. RUNNING

6.1 Running



WARNING

Prior to turning on the power, make sure that the supply voltage meets the specifications for the instrument and the instrument is properly grounded.



CAUTION

This recorder has no power switch.
Prior to turning on the power, make sure that the chart paper is set in the chart holder.
If the printer is activated with no chart paper set, the sprocket drum (cylindrical part) of the chart holder may be damaged.




WARNING

When calibrating data, connect the equipment written in the Section 9.5 of the instruction manual.
Data calibration must be performed correctly.
Therefore, operators possessing knowledge of electricity and control related matters should perform the calibration after careful reading of Sections 7.2 and 9.5 of the instruction manual.
(Shinko Technos is not liable for damages incurred if calibration is performed other than

Once the power is turned on, the display on the front of the door lights. The instrument will be ready to run (user mode) in about 5 seconds, including the initial screen. If the REC lamp is unlit, press the "REC" key to start recording operation.

6.1.1 Status after Initial Screen

- (1) Display screen :The "REC" lamp keeps the status of before power-off.
- (2) Printout data :All printing data and analog recording data of before power-off are cleared.
- (3) Alarm and Diagnosis :Alarm indications and outputs of before power-off are not recovered.
- (4) Data display and Channel number are displayed as follows. Refer to Fig.6.1.



※Returning to the mode before the power OFF.

Fig. 6.1 Display Screen at Power-on

[Note]

- ① When electric power failed, the initialization is performed after power recovery. And it becomes the initial status.
- ② The printout data is eliminated in initialization. Printout operation is not continued after power recovery when the power is turned off during printout.
- ③ When power is turned on, "0" is indicated on the display until the data is retrieved. The number of digits indicated differ, depending on the setting.

6.2 Recording



CAUTION

- ① The instrument checks zero point for every recording. If the printer block is manually moved during recording, a recording position may be dislocated.
- ② In order to protect the chart paper, dot printing is not performed when the distance between the previous dot printing position and the next one for an identical channel is less than 0.3 mm in the chart paper feed direction or less than 0.5 mm in the scale direction.

6.2.1 Recording Colors

Table 6.1 lists the recording colors for each channel in analog recording.

You can select a recording color from 6 colors for every channel.

Table 6.1 Recording Colors(standard)

| Channel No. | Color |
|-------------|--------|
| 1 | Purple |
| 2 | Red |
| 3 | Green |
| 4 | Blue |
| 5 | Brown |
| 6 | Black |

6.3 How to Record

6.3.1 Starting/Stopping Recording

To start/stop recording, press the “REC” key.

To stop, press the “REC” key for 3 seconds or more.

“REC” lamp is unlit when recording stops.

[Note]

- ① When the power is turned on, the previous status continues.
- ② When controlling a start/stop of recording through Digital Input DI function (option : RE6), start / stop cannot be switched by “REC” key.

6.3.2 Feeding the Chart Paper

The chart paper is fed while the “FEED” key is pressed, and stops when released.

6.3.3 Print Sample

Logging on print example and Alarm on print example




Fig. 6.2 Print Sample

[Reference]

Alarm print, Comment print and Date-and-Time print stand by if the other printing is actuated.

HR-706 stores up to six items of Alarm Occurrence/Recovery print and five items of Comment/Date-and-Time print. If printing commands are over, HR-706 prints a marking "*" on the end of the last printing. This mark is meaning of that over items would not be printed.

For priority of respective printing, see next page; Priority in Reference.

[Note]

Logging print will not be the wait printing state. At the start time of Logging print, if the prior Logging print is printing, the next one cannot print. Prolong the printing interval of Logging print in this case.


6.4 Digital Print

Digital prints below are performed by key operation.

- Manual print
- List print
- Engineering list print

[Reference]

Printing is actuated in following priority. See following Priority Order. When multiple types of printing are activated simultaneously, higher-priority printing takes effect first following the priority order. In alarm printing activation, lower category (Logging, DI Manual) also is activated. (See Fig. 6.2 that is example : Time printing of Alarm and Logging print are performed at the same time).



The Synchronous printout synchronizes with the analog recording and prints out digitally. In the case of asynchronous printout, it stops an analog recording and it executes a digital printout. It resumes an analog recording after the digital printout completes.

6.4.1 Manual Print

Prints the following data on the chart paper:

- Time/date (year, month, day)
- Channel number Tag setting character activated alarm type, latest process variable and engineering unit (all channels)

(1) Manual print operating procedure

- ① Press the “PRINT” key.
- ② Use the “PRINT” key to display “**AA**”, and press the “ENT” key.
- ③ Use the “PRINT” key to select “**SEAR**”. Pressing the “ENT” key executes manual print.

Once manual print starts, the display is automatically returned to the Data Display screen.

When manual print is terminated, it is returned to the status prior to starting manual print.

[Note]

- ① Analog recording is interrupted while manual print is running. However, measurement/alarm detection remains effective.
- ② If an alarm is activated while manual print is running, alarm print is performed when manual print is finished.

(2) Manual print stopping procedure

- ① Press the “PRINT” key.
- ② Use the “PRINT” key to display “**PA**”, and press the “ENT” key.
- ③ Use the “PRINT” key to select “**STOP**”. Pressing the “ENT” key stops manual print.

However, print operation continues until the line is completed. Manual print is stopped.

And the display returned to the status prior to starting manual print.




Fig. 6.3 Manual Print

6.4.2 List Print

Prints the following setting data of the instrument on the chart paper:

- Date/time/Chart feed speed/2nd chart feed speed/Printing cycle.
- Channel number/range/scaling value/engineering unit
- Setting alarm type

(1) List print operating procedure

- ① Press the “PRINT” key.
- ② Use the “PRINT” key to display “**LI SE**”, and press the “ENT” key.
- ③ Use the “PRINT” key to select “**SEAR**”. Pressing the “ENT” key executes list print.

Once list print starts, the display is automatically returned to the Data Display screen.

When the list print is terminated, it is returned to the status prior to starting list print.

[Note]

- ① Analog recording is interrupted while list print is running. However, measurement/alarm detection remains effective.
- ② If an alarm is activated while list print is running, alarm print is performed when recording restarts.

(2) List print stopping procedure

- ① Press the "PRINT" key.
- ② Use the "PRINT" key to display "**LI SE**", and press the "ENT" key.
- ③ Use the "PRINT" key to select "**Stop**". Pressing the "ENT" key stops list print.

However, print operation continues until the line is completed. List print is stopped.

And the display returned to the status prior to starting list print.




Fig. 6.4 List Print

6.4.3 Engineering List Print

Engineering list print provides the following setting data of the instrument on the chart paper.

- Analog recording
- Digital printing
- Burnout/RJC etc.

(1) Engineering list print operating procedure

- ① Press the “MENU” key.
- ② Use the “PRINT” key to display “ELI SE”, and press the “ENT” key.
- ③ Use the “PRINT” key to select “SEARt”. Pressing the “ENT” key executes engineering list print.

Once engineering list print starts, the display is automatically returned to the Data Display screen.

When the engineering is terminated, it is returned to the status prior to starting engineering list print.

[Note]

- ① Analog recording is interrupted while engineering list print is running.
However, measurement/alarm detection remains effective.
- ② If an alarm is activated while engineering list print is running, alarm print is performed when recording restarts.

(2) Engineering list print stopping procedure

- ① Press the "MENU" key.
- ② Use the "PRINT" key to display "ELI SE", and press the "ENT" key.
- ③ Use the "PRINT" key to select "Stop". Pressing the "ENT" key stops engineering list print.

However, print operation continues until the line is completed.

Engineering list print stopped. And the display returned to the status prior to starting engineering list print.




Fig. 6.5 Engineering List Print


6.5 Changing the Display

Display selection procedure

- ① Press the “MENU” key to display "**di SP**", and press the “ENT” key.
- ② Use the “PRINT” key to select a required display screen from the menu below.
Press the “ENT” key.
- ③ "**CH**" is displayed in the case of manual display. Use the “PRINT” key to select the channel number. Press the “ENT” key.
 - "**Auto**"(AUTO) : Auto display
 - "**MAN**"(MAN) : Manual display
 - "**DATE**"(DATE) : Date display
 - "**TIME**"(TIME) : Time display
 - "**OFF**"(OFF) : Display off

6.5.1 **Auto**<Auto Display>

Displays the process variable of each channel sequentially at intervals of 2.5 seconds.



6.5.2 **MAN**<Manual Display>


Displays the process variable of the specific channel, it updates every measurement cycle.

The data is the same as Auto display. Pressing the “ENT” key changes the displayed channel number (it increments).

6.5.3 **DATE**<Date Display>

Displays the month and day. Leap year adjustment is automatic.


Example of October 18



6.5.4 **TIME**<Time Display>

Displays hour and minute.

Example of 12:15



6.5.5 **OFF**<Display Off>

Turns off the process variable display. Key operation is the same as usual. To switch to other display, take steps ① through ③ mentioned above.

- 7.1.3 Setting the Unit

| Setting | Channel | Char. No. | Code No. | |
|---------|---------|-----------|----------|-----|
| Unit | Ch1 | 1 | Cd 6F | (°) |
| | . | 2 | Cd 43 | (C) |
| | . | 3 | Cd 00 | End |
| | . | 4 | | |
| | Ch6 | 5 | | |
| | | 6 | | |

- 7.1.4 Setting the Chart feed Speed

| Setting | 1st/2nd Chart speed | Chart speed |
|---------|---------------------|-------------|
| CHAR | SPd-1 | 1500 |
| | SPd-2 | |

- 7.1.5 Setting the Date and Time

| Setting | Year | Month, Day | Time |
|---------|--------|------------|------------|
| CLOCK | Y 2000 | MO 1-01 | TIME 06:00 |

- 7.1.6 Copying the Setting Data

| Setting | Copy-from Channel | Copy-to Channel |
|---------|-------------------|-----------------|
| COPY | F Ch1 | E Ch2 |
| | F Ch2 | E Ch3 |
| | . | . |
| | F Ch5 | E Ch6 |

- 7.1.7 Setting the Other Functions (Printing Cycle, Zone Recording, Partial Compression/Expansion, Digital Print, Tag, Comment Words)

| Setting | Mode | |
|---------|---------|-------------------------------|
| FUNC | trEnd | Printing Cycle |
| | Zone | Zone Recording |
| | PARt | Partial Compression/Expansion |
| | Digital | Digital Print |
| | Tag | Tag |
| | Comment | Comment Words |

- Shift to the engineering mode

| Setting | Password |
|---------|----------|
| ENG | P 0000 |

Input the password to enter the engineering mode.
See the key operation in page 67.

Table 7.1 Initial setting value of the setup mode

| Setting items | Initial setting | Remarks |
|--|--|--|
| ★Range (all channels) | ± 10mV Scaling 0 to 100.0 (°C) | |
| ★Alarm (all channels) | All levels are alarm OFF, relay OFF | |
| ★Engineering unit (all channels) | °C(BF 43 00) | |
| ★Chart feed speed | (1) 20mm/h (2) 20mm/h | |
| ★Time | 2000/01/01, 00:00 | Sets up the present time. (Japan standard time) GMT + 09:00 |
| ★Dot point interval | 10 (s) | |
| ★Zone setting (all channels) | 0 to 100 (%) | |
| ★Partial compression/expansion (all channels) | OFF | |
| ★ Digital print (all channels) | ON | |
| ★Tag print character (all channels) | "Blank up to the 7th character" | |
| ★Comment print word (1 to 3) | "Blank up to the 16th character" | |

7.1.1 Setting the Range

(1) Setting method

With a multirange system, setting the range for each channel is possible.

Use the Δ key to shift the mode ① to ⑩ shown in the Table below.

Set the range from the following input signals. (mode ① to ③)

| | |
|---------------------------------|---|
| DC voltage | : ± 10 , 0 to 20, 0 to 50, ± 200 mVdc, ± 1 , 0 to 5, ± 10 Vdc |
| DC current | : 4 to 20 mAdc (External shunt resistor: 250 Ω) |
| Thermocouple | : B, R, S, K, E, J, T, C, Au-Fe, N, PR40-20, PL II, U, L |
| Resistance temperature detector | : Pt100, JPt100 |

Sets scaling, decade, square root, interchannel sum/difference/average. (mode ④ to ⑨)

Unnecessary channels can be skipped. (mode ⑩)

| Setting | Channel | Mode | Key |
|---------|--|---|--------------|
| RANGE | CH 1 CH 2 CH 3 CH 4 CH 5 CH 6 Setting for all channels | ① VOLt (Voltage, Current) | Δ key |
| | | ② tC (Thermocouple) | ↓ |
| | | ③ rtd (Resistance temperature detector) | ↓ |
| | | ④ SCALE (Scaling) | ↓ |
| | | ⑤ SQrt (Square root) | ↓ |
| | | ⑥ decAd (Decade) | ↓ |
| | | ⑦ dELt (Difference) | ↓ |
| | | ⑧ SUM (Sum) | ↓ |
| | | ⑨ AEAr (Average) | ↓ |
| | | ⑩ SKI P (Skip) | ↓ |

[Note]






























A decimal point arbitrary position can be set only in the "scaling" and "square root" modes. When you want to alter the decimal point position in Voltage/Current/Thermocouple/Resistance temperature detector input set it in the "scaling" mode. To fix the decimal point position, set it as follows.

| Input | Decimal Places | Input | Decimal Places |
|-------------------|-------------------------|----------------|--------------------------|
| mV | 2nd place * * * . 00 | Thermocouple | 1st place * * * * . 0 |
| ± 1 , 0 to 5V | 3rd place * * . 000 | RTD | 1st place * * * * . 0 |
| ± 10 V | 2nd place * * * . 00 | ± 200 mVdc | 1st place * * * * . 0 |
| mA | 2nd place * * * . 00 | | |





(2) **mA**(Current/Voltage), **TC**(Thermocouple), **RTD**(Resistance Temperature Detector)

Measures Current, Voltage, Thermocouple and RTD.

Example) When setting Thermocouple T for Channel 1(T :-100 to 300 °C)

| Display | Operation keys | Description |
|---|--|---|
|   |  3sec  | Press the “MENU” key for 3 seconds or more to enter the setup mode. Displays “rANGE”, then, press the “ENT” key. |
|   |   | Use the Δ key to select the channel you want to set. Press the “ENT” key. |
|   |   | Use the Δ key to select the mode. Press the “ENT” key. |
|   |   | Use the Δ key to select the type. Press the “ENT” key. |
|   (Zero setting) |    | Use the Δ key to select a sign and numeral. Use the \triangleright key to shift a digit. Press the “ENT” key. |
|   (Span setting) |    | Use the Δ key to select a sign and numeral. Use the \triangleright key to shift a digit. Press the “ENT” key. |
|   |  | Press the “ENT” key. Setting is completed. To return to the user mode, press the “MENU” key for 3 seconds or more. |


[Note]

- ① When an incorrect numeral is input displays an error,   or  . Press the “ENT” key and re-enter a correct numeral.
- ② For the range setting (When especially, don't change a decimal point position at the thermocouple or in RTD) which doesn't have the necessity of the scaling, don't set a scaling.

[Note]

In the **Volte**, **EC**, or **red** mode, press the “ENT” key to select the range.

Use the Δ key, you can select the type.























(3) **SCALE**(Scaling)

Changes the input of VOLT, TC and RTD into a quantity.





Setting the unit is possible.(See 7.1.3 on page 56)

Example) When setting the voltage of 0 to 40 mV and scale of 000.00 to 100.00 for Channel 1.

| Display | Operation keys | Description |
|---|--|---|
|  |  3sec   | Press the “MENU” key for 3 seconds or more to enter the setup mode. Use the Δ key to display “r-RANGE”. Press the “ENT” key. |
|  |   | Use the Δ key to select the channel you want to set. Press the “ENT” key. |
|  |   | Use the Δ key to select “SCALE”. Press the “ENT” key. |
|  |   | Use the Δ key to select “Volte”. Press the “ENT” key. If tc or rtcd is selected here, temperature input scaling is possible. |
|  |   | Use the Δ key to select a range(50 mV). Press the “ENT” key. |
|  (Zero input value) |    | Use the Δ key to select a numeral. Use the \triangleright key to shift a digit. Press the “ENT” key. |

[Note]

In the case of TC and RTD input, set the Zero input value equal to the Zero-side scale value.
But, set a decimal point position to the standard position. (* 1:next page)


| | | |
|---|--|--|
|  (Span input value) |    | Use the Δ key to select a numeral. Use the \triangleright key to shift a digit. Press the “ENT” key. |
|---|--|--|

[Note]

In the case input, set the Span input value equal to the Span-side scale value.
But, set a decimal point position to the standard position. (* 2:next page)



(Zero-side scale value) (* 1)




Use the Δ key to select a numeral.


Use the \triangleright key to shift a digit.




(Decimal point)



Press the \triangleright key again in the lowest digit(right end) to blink a decimal point. Use the Δ key to select a decimal point position. Press the “ENT” key.




(Span-side scale value) (*)



Use the Δ key to select a numeral.

Use the \triangleright key to shift a digit. Press the “ENT” key.







Press the “ENT” key. Setting is completed.

To return to the user mode, press the “MENU” key for 3 seconds or more.

[Note]

When an incorrect numeral is input, the display indicates error   ,

  or   .



































Press the “ENT” key and re-enter a correct numeral.

(4) **SqrE**(Square Root)

Calculates the square root of Volt input, and scaling that value.

Setting the unit is possible. (See 7.1.3 on page 56)

Example) When setting the voltage of 0 to 40 mV and scale of 000.00 to 100.00 for Channel 1.

| Display | Operation keys | Description |
|--|--|---|
|  r-RnGE |  MENU 3sec   | Press the “MENU” key for 3 seconds or more to enter the setup mode. Use the Δ key to display “r-RnGE”. Press the “ENT” key. |
|  Ch 1 |   | Use the Δ key to select the channel you want to set. Press the “ENT” key. |
|  SqrE |   | Use the Δ key to select “SqrE”. Press the “ENT” key. |
|  50mV |   | Use the Δ key to select a range(50 mV). Press the “ENT” key. |
|  000.00 (Zero input value) |    | Use the Δ key to select a numeral. Use the \triangleright key to shift a digit. Press the “ENT” key. |
|  040.00 (Span input value) |    | Use the Δ key to select a numeral. Use the \triangleright key to shift a digit. Press the “ENT” key. |
|  0000.0 (Zero-side scale value) |   | Use the Δ key to select a numeral. Use the \triangleright key to shift a digit. |
|  000.00 (Decimal point) |    | Press the \triangleright key again in the lowest digit(right end) to blink a decimal point. Use the Δ key to select a decimal point position. Press the “ENT” key. |
|  100.00 (Span-side scale value) |    | Use the Δ key to select a numeral. Use the \triangleright key to shift a digit. Press the “ENT” key. |
|  -SEt- |  | Press the “ENT” key. Setting is completed. To return to the user mode, press the “MENU” key for 3 seconds or more. |

[Note]

When an incorrect numeral is input,

E

Err21

,

E

Err24

or **E** **Err25** is displayed.

Press the “ENT” key and re-enter a correct numeral.

About Square Root Computation

The square root computation is as follows:

- Each item is defined as follows:
 - SPAN_L : Span lower-limit value (Span L)
 - SPAN_R : Span upper-limit value (Span R)
 - SCAL_L : Scaling lower-limit value (Scale L)
 - SCAL_R : Scaling upper-limit value (Scale R)
 - IN : Input voltage
 - OUT : Output (Scaling value)

- When an input value is 1 % or more (1 to 100 %)

$$OUT = (SCAL_R - SCAL_L) \times \sqrt{\frac{IN - SPAN_L}{SPAN_R - SPAN_L}} + SCAL_L$$

- When an input value is less than 1 %

$$OUT = \frac{10 \times (SCAL_R - SCAL_L)}{SPAN_R - SPAN_L} \times (IN - SPAN_L) + SCAL_L$$

Example) When setting as in the previous page, the display is as following table.

| | | | | | |
|--------------------|-------|--------|--------|--------|---------|
| Input voltage (mV) | 0 | 10 | 20 | 30 | 40 |
| Display (%) | 0. 00 | 50. 00 | 70. 71 | 86. 63 | 100. 00 |
































[Note]

The relation between scaling factor and displaying digit may stagger the accuracy rating.

(5) **dECAd**(Decade)

Scaling the VOLT input and displays the index number. Setting the unit is possible. (See 7.1.3 on page 56)

Example) When setting the voltage of 0 to 5 V and decade of 1.0×10^0 to 1.0×10^5 for Channel 1.

| Display | Operation keys | Description |
|---|--|---|
|  rAnGE |  3sec   | Press the “MENU” key for 3 seconds or more to enter the setup mode. Use the Δ key to display “rAnGE”. Press the “ENT” key. |
|  Ch 1 |   | Use the Δ key to select the channel you want to set. Press the “ENT” key. |
|  dECAd |   | Use the Δ key to select “dECAd”. Press the “ENT” key. |
|  5V |   | Use the Δ key to select a range(5V). Press the “ENT” key. |
|  00.000 (Zero input value) |    | Use the Δ key to select a numeral. Use the \triangleright key to shift a digit. Press the “ENT” key. |
|  05.000 (Span input value) |    | Use the Δ key to select a numeral. Use the \triangleright key to shift a digit. Press the “ENT” key. |
|  10E00 (Zero-side scale value) |    | Use the Δ key to select a numeral. Use the \triangleright key to shift a digit. Press the “ENT” key. |
|  10E05 (Span-side scale value) |    | Use the Δ key to select a numeral. Use the \triangleright key to shift a digit. Press the “ENT” key. |
|  -SEt- |  | Press the “ENT” key. Setting is completed. To return to the user mode, press the “MENU” key for 3 seconds or more. |

[Note]

When an incorrect numeral is input



E r r 2 1

,



E r r 2 4

or



E r r 2 5

is displayed.

Press the “ENT” key and re-enter a correct numeral.

About Decade Display

- Each item is defined as follows:

| | | |
|-------------------|--------------------------------------|---------|
| SPAN _L | : Span low limit value (Span L) | |
| SPAN _R | : Span high limit value (Span R) | |
| SCAL _L | : Scaling low limit value (Scale L) | } XXEYY |
| SCAL _R | : Scaling high limit value (Scale R) | |
| IN | : Input voltage | |
| OUT | : Output (Scaling value) | |

XX: Mantissa section (1.0 to 9.9)

YY: Exponent section (-19 to 19)

Up to 5 decades.

(Scaling upper limit) – (Scaling lower limit) is 1.0E5 or less.

- Decade display abides by the following relational expression.

$$OUT1 = IN \times \frac{LG\ SCAL_R - LG\ SCAL_L}{SPAN_R - SPAN_L} + \frac{SPAN_R \times LGSCAL_L - SPAN_L \times LGSCAL_R}{SPAN_R - SPAN_L}$$

$$OUT = 10^{OUT1}$$

LG SCAL_L : Log₁₀(SCAL_L)

LG SCAL_R : Log₁₀(SCAL_R)

[Note]

Decade output is used for display and print. It is not reflected on a printing position.































Example) When setting as in the previous page, the display is as following table.

| | | | | | |
|-------------------|--------|--------|--------|--------|--------|
| Input voltage (V) | 0. 0 | 1. 0 | 2. 5 | 3. 0 | 5. 0 |
| Display | 1. 0E0 | 1. 0E1 | 3. 2E2 | 1. 0E3 | 1. 0E5 |

(6) **dELt**(Difference), **SuM**(Sum), **AVER**(Average)

Calculates the input of VOLT, TC, RTD or SCALE, and output.

Example) When subtracting the Ch 1 input data from the Ch 6 input data to set the difference (0 to 40 mV). Records and displays on Ch 6 "Ch 6 (input) - Ch 1(input)".

| Display | Operation keys | Description |
|--|---|---|
|  |   3sec    | Press the "MENU" key for 3 seconds or more to enter the setup mode. Use the Δ key to display "rAnGE". Press the "ENT" key. |
|  (Setting channel) |    | Use the Δ key to select the channel you want to set. Press the "ENT" key. |
|  |    | Use the Δ key to select "dELt". Press the "ENT" key. |
|  (Reference channel) |    | Use the Δ key to select the "channel you want to subtract." Press the "ENT" key. |
|  (Zero input value after difference operation) |     | Use the Δ key to select a numeral. Use the \triangleright key to shift a digit. Press the "ENT" key. |
|  (Span input value after difference operation) |     | Use the Δ key to select a numeral. Use the \triangleright key to shift a digit. Press the "ENT" key. |
|  |  | Press the "ENT" key. Setting is completed. To return to the user mode, press the "MENU" key for 3 seconds or more. |

[Note]



When an incorrect numeral is input





, 



or   is displayed.

Press the "ENT" key and re-enter a correct numeral.




















About Difference, Sum, and Average

- The setting channel must be larger than the one on which computes the "difference, sum, or average". When setting Channel 6, for example, you can subtract the Channel 1 to 5 value.
- The range and scale of the setting channel is the same as the channel on which computes the "difference, sum, and average".
- A range value after the computation cannot exceed the maximum range of the instrument.
- Set for the reference channel only the voltage, current, thermocouple, resistance temperature detector, and their scaling ranges.



(7) **SEI P**(Skip)

Setting SKIP on the Channel that does not display and record.

Example) When skipping Channel 6.

| Display | Operation keys | Description |
|---|---|--|
|   |  3sec    | Press the “MENU” key for 3 seconds or more to enter the setup mode. Use the Δ key to display “r-RnGE”. Press the “ENT” key. |
|   |    | Use the Δ key to select the channel you want to set. Press the “ENT” key. |
|   |    | Use the Δ key to select “SEI P”. Press the “ENT” key. |
|   |  | Press the “ENT” key. Setting is completed. To return to the user mode, press the “MENU” key for 3 seconds or more. |

[Note]

Setting all the channels to Skip displays an error,   .
At least, one channel should be set to measurement.

About Skip

- The skip channel measures, but does not display, print, nor assess alarms. If input is not connected, short-circuit a measurement terminal.

7.1.2 Setting the Alarm

Setting items

Alarm setting to the following 2 types for each channel is possible.

Alarm point can be set up to 4 levels per channel.

Once alarm point is set up "ALM" when a process variable reaches alarm point, and simultaneously, outputs the alarm print indicating an alarm occurrence to the chart paper.

H: High limit alarm ---- When the process variable is higher than the alarm setting point, issues an alarm.

L: Low limit alarm ---- When the process variable is lower than the alarm setting point, issues an alarm.

Operation

| Setting | Channel | Level | ON/OFF | Type | Setting value | Option | |
|---------|---------|-------|--------|------|---------------|--------------|-----------|
| | | | | | | Relay ON/OFF | Relay No. |
| ALARM | CH1 | L1 | on | H | -2.000 | on | 1 |
| | . | L2 | off | L | | off | . |
| | . | L3 | | | | | . |
| | . | L4 | | | | | . |
| | CH6 | | | | | | 6 |

Example) When setting for the Channel 1 alarm point (Level 1) the high limit alarm, set the value of -2.000, and alarm output relay No. 1.

| Display | Operation keys | Description |
|---------------------|--------------------------|--|
| <div>ALA-ā</div> | ESC MENU 3sec | Press the "MENU" key for 3 seconds or more to enter the setup mode. Use the Δ key to display "ALA-ā". Press the "ENT" key. |
| <div>CH1</div> | Δ PRINT ENT | Use the Δ key to select the channel you want to set. Press the "ENT" key. |
| <div>1 L1</div> | Δ PRINT ENT | Use the Δ key to select an alarm level. Press the "ENT" key. Up to 4 levels can be set. |
| <div>1 on</div> | Δ PRINT ENT | Use the Δ key to select alarm setting ON. Press the "ENT" key. Setting "off" displays "ALA-ā" and completes setting. |
| <div>1 H</div> | Δ PRINT ENT | Use the Δ key to select an alarm type. Press the "ENT" key. |
| <div>1 -2.000</div> | Δ Δ PRINT FEED ENT | Set an alarm point. Use the ▷ key to shift a digit, and use the Δ key to select a numeral. Once setting is completed, press the "ENT" key. A decimal point position is fixed depending on the range. |

[Note]

When the “ENT” key is pressed during alarm point setting. Display will be switched to the next setting display

Setting hereinafter is valid only for the model to which an alarm output (option : LH6) has been attached. If the option has not been set, press the “ENT” key until “-SEt-” is displayd.

Then, press the “ENT” key once more. Setting is completed.

| Display | Operation keys | Description |
|--|--|--|
| <div><div>{</div><div>on</div></div> | <div><div><div>△</div></div><div>PRINT</div><div>ENT</div></div> | <p>When an alarm occurs, issues the alarm output from the alarm output relay. Use the △ key to select alarm output ON and press the “ENT” key.</p> <p>If the alarm output is not used, select OFF and press the “ENT” key.</p> |
| <div><div>{</div><div>{</div></div> | <div><div><div>△</div></div><div>PRINT</div><div>ENT</div></div> | <p>If the alarm output is set to ON, set the relay number. Use the △ key to select the relay number out of 1 to 6, and press the “ENT” key.</p> |
| <div><div></div><div>-SEt-</div></div> | <div><div>ENT</div></div> | <p>Press the “ENT” key. Setting is completed.</p> <p>When you want to continue to set for other channel, press the △ key to select the channel, and start setting. To return to the user mode, press the “MENU” key for 3 seconds or more.</p> |

[Note]

The tag setting does not effect on Alarm print setting. Prints channel numbers every time.

7.1.3 Setting the Unit

Setting Items

Sets the unit for each channel.







[Note]

If you change the unit in the range of **Wolt**, **EC** or **red**, set the range to **SCALE**.

Operation

| Setting | Channel | Char. No. | Code No. |
|---------|---------|-----------|-----------|
| Unit | Ch1 | 1 | Cd bF (°) |
| | . | 2 | Cd 43 (C) |
| | . | 3 | |
| | . | 4 | |
| | Ch6 | 5 | |
| | | 6 | |
| | | | End |





Example) Setting the unit(°C) for Channel 1.

| Display | Operation keys | Description |
|---|------------------------------------|---|
|  | ESC MENU 3sec △ PRINT ENT | Press the “MENU” key for 3 seconds or more to enter the setup mode. Use the △ key to display “Unit”. Then, press the “ENT” key. |
|  | △ PRINT ENT | Use the △ key to select the channel you want to set. Then, press the “ENT” key. |
|  | △ ▸ PRINT FEED ENT | Use the △ or ▸ key to select the 1st character of the code number, and press the “ENT” key. See Characters Code Table on the next page. |
|  | △ ▸ PRINT FEED ENT | Set the 2nd character in the same manner. |
|  | △ ▸ PRINT FEED ENT | When the number of unit characters is less than 6, enter a code(00) to end. Press the “ENT” key. |
|  | ENT | Press the “ENT” key. Setting is completed. To return to the user mode, press the “MENU” key for 3 seconds or more. |

[Note]

The unit setting is effective only when the range setting is **SCALE**, **Scale** or **DECAd** (including **del**, **S**, **CA** and **FEAR** when **SCALE** is selected as the reference channel. When the range setting is others, the unit is determined according to the range automatically.

(1) Character code table

| | 2 * | 3 * | 4 * | 5 * | 6 * | 7 * | A * | B * | C * | D * | E * | F * |
|----|-----|-----|-----|-----|-----|-----|--------------|--------------|-----|---|-----|-----|
| *0 | SP | 0 | @ | P | | p | ₀ | ⁰ | | Π | | π |
| *1 | ! | 1 | A | Q | a | q | ₁ | ¹ | A | P | α | ρ |
| *2 | " | 2 | B | R | b | r | ₂ | ² | B | Σ | β | σ |
| *3 | # | 3 | C | S | c | s | ₃ | ³ | Γ | T | γ | τ |
| *4 | \$ | 4 | D | T | d | t | ₄ | ⁴ | Δ | Υ | δ | υ |
| *5 | % | 5 | E | U | e | u | ₅ | ⁵ | E | Φ | ε | φ |
| *6 | & | 6 | F | V | f | v | ₆ | ⁶ | Z | X | ξ | χ |
| *7 | ' | 7 | G | W | g | w | ₇ | ⁷ | H | Ψ | η | ψ |
| *8 | (| 8 | H | X | h | x | ₈ | ⁸ | Θ | Ω | θ | ω |
| *9 |) | 9 | I | Y | i | y | ₉ | ⁹ | I | | ι | |
| *A | * | : | J | Z | j | z | | | K | | κ | |
| *B | + | ; | K | [| k | { | ₊ | ⁺ | Λ | | λ | |
| *C | , | < | L | ¥ | l | | _± | [±] | M |  | μ | |
| *D | — | = | M |] | m | } | | | N |  | ν | |
| *E | . | > | N | ^ | n | — | _— | [—] | Ξ |  | ξ | |
| *F | / | ? | O | — | o | | _o | ^o | O |  | o | |

Setting example) The code number for "C" is "43".

7.1.4 Setting the Chart feed speed

Setting Items

Sets the chart feed speed. Select it from the table below.










Table 7.2 Chart Speed (Unit: mm/h)

| | | | | | | | | | |
|-----|-----|------|------|-----|-----|-----|-----|-----|-----|
| 0 | 1 | 2 | 3 | 4 | 5 | 10 | 15 | 20 | 25 |
| 30 | 40 | 50 | 60 | 75 | 80 | 90 | 100 | 120 | 150 |
| 160 | 180 | 200 | 240 | 300 | 360 | 375 | 450 | 600 | 720 |
| 750 | 900 | 1200 | 1500 | | | | | | |

Operation







| Setting | 1st/2nd Chart feed speed | Chart feed speed |
|---------|--------------------------|------------------|
| CHAR-E | SPd-1 SPd-2 | 1500 |

Example) When setting the 1st chart feed speed to 1500 mm/h.

| Display | Operation keys | Description |
|--|--|---|
|  CHAR-E |  3sec   | Press the "MENU" key for 3 seconds or more to enter the setup mode. Use the  key to display "CHAR-E", and press the "ENT" key. |
|  SPd-1 |   | Use the  key to select the 1st chart feed speed, and press the "ENT" key. |

[Note]

When altering the chart feed speed with the DI function (option : RE6), set the 2nd chart feed speed. If the DI function (option : RE6) is not attached, setting of the 2nd chart feed speed becomes invalid.

| Display | Operation keys | Description |
|--|---|---|
|  1500 |   | Use the  key to set the 1st chart feed speed, and press the "ENT" key. |
|  -SEt- |  | Press the "ENT" key. To return to the user mode, press the "MENU" key for 3 seconds or more. |

[Note]





Restriction of printing
by chart feed speed

| Print type | Chart speed (mm/h) |
|--|--------------------|
| Alarm occurrence print, Alarm recovery print, Affix print, DI Comment print (Synchronous), DI Date and Time print (Synchronous), DI Manual print (Synchronous) | 1 to 100 |
| Logging print (Synchronous) | 10 to 100 |
































When the chart speed is 0 mm/h, it's printed with forcible chart feed. (When the chart feed speed is more than 120 mm/h, the table shown above is not printed.) List Print, Engineering List Print, Manual Print (key), DI Comment print (Asynchronous), DI Date and Time print (Asynchronous), DI Manual print (Asynchronous) and Logging print (Asynchronous) is printed regardless of the chart feed speed.

7.1.5 Setting the Date and Time**Operation**



The following figure describes how to set the date/time of the internal clock.

| Setting | Year | Month, Day | Time |
|---|---|---|--|
|  |  |  |  |
| CLoCK | Y 2000 | M 01-01 | E 06:00 |

Example) When setting the date and time to January 1st, 2000, 6:00.

| Display | Operation keys | Description |
|---|---|--|
|   |   3sec | Press the "MENU" key for 3 seconds or more to enter the setup mode. Use the  key to display "CLoCK," and press the "ENT" key. |
|   |        | Set the year. Use the  key to select a numeral, and use the  key to shift a digit. Press the "ENT" key. |
|   |     | Set the month and day. Operate in the same manner as setting the year. |
|   |     | Set the time (hours and minutes). Operate in the same manner as setting the year. |
|   |  | Press the "ENT" key. To return to the user mode, press the "MENU" key for 3 seconds or more. |

[Note]

If you enter a non-existent date or time, an error   is displayed.

Press the "ENT" key and re-enter a correct numeral.

7.1.6 Copying the Setting Data

Setting Items

The following figure describes how to copy the setting data of any channel to the other channel.

The number of the original channel must be bigger than the channel to be copied.

Operation

| Setting | Original channel | Channel to be copied |
|---------|------------------|----------------------|
| CoPY | F CH1 | E CH2 |
| | F CH2 | E CH3 |
| | ⋮ | ⋮ |
| | F CH5 | E CH6 |

Example) When copying the setting data of Channel 1 to Channel 2.

| Display | Operation keys | Description |
|-------------------|---|--|
| <div></div> CoPY | <div>ESC</div> <div>MENU 3sec</div> | Press the "MENU" key for 3 seconds or more to enter the setup mode. Use the Δ key to display "CoPY", and press the "ENT" key. |
| <div>F</div> CH1 | <div>Δ</div> <div>PRINT ENT</div> | Use the Δ key to select the original channel, and press the "ENT" key. |
| <div>E</div> CH2 | <div>Δ</div> <div>PRINT ENT</div> | Use the Δ key to select the channel to be copied, and press the "ENT" key. |
| <div></div> -SEt- | <div>ENT</div> | Press the "ENT" key. To return to the user mode, press the "MENU" key for 3 seconds or more. |

7.1.7 Setting the other functions

Setting the other functions as follows is possible.

Setting Items

① **trEnd**(Printing cycle)

Selects a printing cycle from 10, 20, 30, and 60 seconds.

② **Zone**(Zone recording)

The data for each channel can be recorded separately in another area so as not to overlap.

③ **PARt**(Partial compression/expansion)

Records the measured data of the channel, partially compressed or expanded.

④ **Print**(Digital print)

Specify ON or OFF whether the measured data for each channel is to be printed or not.

⑤ **TAG**(Tag)

Sets the tag, which is to be printed instead of a channel number, for logging print or manual print.

Setting the tag up to 7 characters (select from character code table on page 57), for each channel is possible.

⑥ **Cmt**(Comment words)

Sets the comment words to be printed by DI function (Option : RE6).
















There are 3 kinds of comment words and setting up to 16 characters (select from character code table on page 57) for each DI is possible.

Operation

| Setting | Mode | |
|--------------|--|--|
| Print | trEnd Zone PARt Print TAG Cmt | Printing Cycle Zone Recording Partial Compression/Expansion Digital Print Tag Comment Words |


























(1) **trEnd**(Printing Cycle)

Example) Setting the printing cycle to 60 seconds.





| Display | Operation keys | Description |
|---|--|--|
|  |     | Press the “MENU” key for 3 seconds or more to enter the setup mode. Use the Δ key to display “ RUN ”, and press the “ENT” key. |
|  |    | Use the Δ key to display “ trEnd ”, and press the “ENT” key. |
|  |    | Use the Δ key to select the printing cycle “ 60 ”, and press the “ENT” key. |
|  |  | Press the “ENT” key. Setting is completed. To return to the user mode, press the “MENU” key for 3 seconds or more. |

(2) **Zone**(Zone Recording)

Example) Setting the instrument so that Channel 1 zero/span will be recorded at the position of 20 to 50 %.


| Display | Operation keys | Description |
|--|--|--|
|  |     | Press the “MENU” key for 3 seconds or more to enter the setup mode. Use the Δ key to display “ RUN ”, and press the “ENT” key. |
|  |    | Use the Δ key to display “ Zone ”, and press the “ENT” key. |
|  |    | Use the Δ key to select the channel you want to set, and press the “ENT” key. |
|  (Setting of Left-end Position) |     | Set a zero point printing position in percentage (%). Use the Δ key to select a numeral, and use the \triangleright key to shift a digit. Press the “ENT” key. |
|  (Setting of Right-end Position) |     | Set a span printing position in percentage (%). Operate in the same manner as setting the zero point printing position. |
|  |  | Press the “ENT” key. Setting is completed. To return to the user mode, hold down the “MENU” key for 3 seconds or more. |

[Note]

If you enter an incorrect numeral, errors   or   is displayed.
Press the “ENT” key and re-enter a correct numeral.

(3) **PARt**(Partial Compression/Expansion)

Example) Setting Channel 1 scale of 0 to 1,000.0 °C to 500.0 °C at a boundary point of 30 %.



| Display | Operation keys | Description |
|---------|----------------|--|
| | 3sec | Press the “MENU” key for 3 seconds or more to enter the setup mode. Use the Δ key to display “RUN”, and press the “ENT” key. |
| | | Use the Δ key to select “PARt”, and press the “ENT” key. |
| | | Use the Δ key to select the channel you want to set, and press the “ENT” key. |
| | | Use the Δ key to select “on”, and press the “ENT” key. |
| | | Set a boundary point position in percentage (%). Use the Δ key to select a numeral, and use the \triangleright key to shift a digit. Press the “ENT” key. |
| | | Set a boundary point position to “0500.0”. Use the Δ key to select a numeral, and use the \triangleright key to shift a digit. Press the “ENT” key. |
| | | Press the “ENT” key. Setting is completed. To return to the user mode, press the “MENU” key for 3 seconds or more. |

[Note]

If you enter an incorrect numeral, an error is displayed.
Press the “ENT” key and re-enter a correct numeral.

(4) Print (Digital Print)

Example) Setting logging channel data print to "ON"(print enabled) for all the channels.

| Display | Operation keys | Description |
|--------------------------------|---|--|
| <input type="checkbox"/> RUN | ^{ESC} MENU 3sec △ PRINT ENT | Press the "MENU" key for 3 seconds or more to enter the setup mode. Use the △ key to display "RUN", and press the "ENT" key. |
| <input type="checkbox"/> Print | △ PRINT ENT | Use the △ key to display "Print", and press the "ENT" key. |
| <input type="checkbox"/> CH 1 | △ PRINT ENT | Use the △ key to select the channel you want to set, and press the "ENT" key. |
| <input type="checkbox"/> OFF | △ PRINT ENT | Use the △ key to switch from "OFF" to "ON", and press the "ENT" key. |
| <input type="checkbox"/> -SEt- | ENT | Press the "ENT" key. Setting is completed. |
| <input type="checkbox"/> CH2 | △ PRINT ENT | Repeat setting for each channel. |
| ⋮ | | |
| <input type="checkbox"/> CH6 | △ PRINT ENT | |
| <input type="checkbox"/> -SEt- | ENT | |

[Note]

When the channel which selected skip in the range setting is set ON, "*" is printed.

(5) **ABC**(Tag)

Example) Setting "ABCD" for Channel 1.

| Display | Operation keys | Description |
|--------------------------------|----------------|--|
| | 3sec | Press the "MENU" key for 3 seconds or more to enter the setup mode. Use the Δ key to display "RUN", and press the "ENT" key. |
| | | Use the Δ key to display "ABC", and press the "ENT" key. |
| | | Use the Δ key to select the channel you want to set, and press the "ENT" key. |
| (Setting of 1st Character) | | Set "4 1" as the 1st character. Use the Δ key to select a code, and use the \triangleright key to shift a digit. Press the "ENT" key. |
| (Setting of 2nd Character) | | Set the 2nd to the 4th characters in the same manner. |
| (Setting of 3rd Character) | | |
| (Setting of 4th Character) | | |
| (Setting of 5th Character) | | Set "00" as the 5th character and press the "ENT" key. |
| | | Press the "ENT" key. Setting is completed. To return to the user mode, press the "MENU" key for 3 seconds or more. |

[Note]

When the number of tag characters is less than 7, set the "00" code following the last character.
See page 57 for Character code table.

(6) **Cānē**(Comment Words)

Example) Setting "ON" for Comment 1(**Cāē 1**).

| Display | Operation keys | Description |
|---------------------------------|----------------|---|
| | 3sec | Press the "MENU" key for 3 seconds or more to enter the setup mode. Use the Δ key to display "ALL", and press the "ENT" key. |
| | | Use the Δ key to display "Cāē", and press the "ENT" key. |
| | | Use the Δ key to select a comment number. Display "Cāē 1" and press the "ENT" key. |
| (Setting of 1st Character) | | Set "4F" as the 1st character. Use the Δ key to select a code, and use the \triangleright key to shift a digit. Press the "ENT" key. |
| (Setting of 2nd Character) | | Set "4E" as the 2nd character. Operate in the same manner as setting the 1st character. |
| (Setting of 3rd Character) | | Set "00" as the 3rd character. Operate in the same manner as setting the 1st character. |
| (Setting of 9th Character) | | Repeat setting for each channel. |
| (Setting of 10th Character) | | |
| (Setting of 11th Character) | | |
| (Setting of 16th Character) | | |
| | | Press the "ENT" key. Setting is completed. To return to the user mode, press the "MENU" key for 3 seconds or more. |

[Note]

- When the number of tag characters is less than 16, set the "00" code following the last character. See page 57 for Character code table.
- When DI (option: RE6) is not designated, comment print does not function.
Do not set the comment setting.

7.2 Setting the Engineering Mode to use this more smoothly.



WARNING

When calibrating data, connect the equipment written in the Section 9.5 of the instruction manual.
Data calibration must be performed correctly.

Operators possessing knowledge of electricity and control related matters should perform the calibration after careful reading the Sections 7.2 and 9.5 of the instruction manual.
(Shinko Technos is not liable for any damages incurred if calibration is performed other than described in the instruction manual.)

Key Operation to Enter the Engineering Mode

Press the "MENU" key for 3 seconds or more to enter the setup mode.
Use the Δ key to select "E-0", and press the "ENT" key then to display "0000".
Use the Δ key to alter a numeral, and the \triangleright key to shift a digit, enter the password "2222".
Press the "ENT" key then to display blinking "rESEt".
Press the "ENT" key. After reset, it enters the engineering mode.

The following figure describes how to set the following items.

The following figure shows a display map of the Engineering mode. Use the Δ key to operate.

● 7.2.1 Alarm Hysteresis

| Setting | ON/OFF | |
|---------|-----------|---|
| ALHYS | ON OFF | Sets the hysteresis width Cancels the hysteresis width |

● 7.2.2 Burnout ON/OFF

| Setting | Channel | ON/OFF | |
|---------|--|-----------|---------------------------------|
| bOUT | CH1 CH2 CH3 CH4 CH5 CH6 | ON OFF | Sets burnout Cancels burnout |

● 7.2.3 Channel Offset

| Setting | Channel | OFFSET | |
|---------|--|--------|-----------------------|
| oFSEt | CH1 CH2 CH3 CH4 CH5 CH6 | 0.0000 | Enter an offset value |

● 7.2.4 Reference Junction Compensation

| Setting | Channel | Function | |
|---------|--|------------------|---|
| rJC | CH1 CH2 CH3 CH4 CH5 CH6 | Int Ext Ch | Internal Compensation External Compensation External Channel Input Compensation |

- 7.2.5 Changing the Printing Color

| Setting | Channel | COLOR | |
|---------|---------|-------|--------|
| Color | CH1 | P-P | Purple |
| | CH2 | Red | Red |
| | CH3 | Green | Green |
| | CH4 | Blue | Blue |
| | CH5 | Brown | Brown |
| | CH6 | Black | Black |

- 7.2.6 Settings Related to Recording

| Setting | Function | |
|---------|----------|--|
| Run | RunEC | Recording start/stop INT/EXT selection |
| | TagC | Tag/channel print selection |
| | ALARM | Alarm print ON/OFF |
| | dGePr | Logging print ON/OFF |
| | SCALE | Scale print ON/OFF |
| | dSYnC | Logging print Synchronous/Asynchronous print selection |

- 7.2.7 Setting the Communication Function

| Setting | Setting the Communication Function |
|---------|--|
| Com | Local Address Data transfer rate Data Length Parity Bit Stop Bit |

- 7.2.8 Initializing the Setup Data

| Setting | YES/NO |
|---------|-----------|
| Init | YES NO |

- 7.2.9 DI Functions

| Setting | DI No. | Function | |
|---------|--------|---------------|-----------------------------------|
| di | di 1 | OFF | No function |
| | di 2 | RunEC | Recording start/stop |
| | di 3 | SPED | Chart feed speed selection |
| | di 4 | Comment 1 | Comment 1 print(Synchronous) |
| | di 5 | Comment 2 | Comment 2 print(Synchronous) |
| | di 6 | Comment 3 | Comment 3 print(Synchronous) |
| | di 7 | Manual print | Manual print(Synchronous) |
| | di 8 | Date and time | Date and time print(Synchronous) |
| | di 9 | Comment 1 | Comment 1 print(Asynchronous) |
| | di 10 | Comment 2 | Comment 2 print(Asynchronous) |
| | di 11 | Comment 3 | Comment 3 print(Asynchronous) |
| | di 12 | Manual print | Manual print(Asynchronous) |
| | di 13 | Date and time | Date and time print(Asynchronous) |

- 7.2.10 Temperature Unit selection

| Setting | Temp Unit | |
|---------|-----------|-----------------|
| TEMP | C | Centigrade Unit |
| | F | Fahrenheit Unit |

- 7.2.11 Point Calibration

| Setting | Function |
|---------|------------------------------|
| P ADJ | Zero FULL HYS Color |

Zero point calibration
Span point calibration
Hysteresis at left/right move (Factory adjustment item)
Ribbon select calibration (Factory adjustment item)

- 7.2.12 Data Calibration

| Setting | Function |
|---------|--------------------|
| d ADJ | VOLT rtd rJC |

Voltage calibration
Resistance temperature detector calibration
Internal reference junction compensation calibration

- 7.3 Terminating the Engineering Mode

| Setting | Function |
|---------|----------------|
| End | Store Abort |

Saves a setting value
Cancels a setting value

[Note]

When terminating the Engineering mode if you select "End" and turn off the power without carrying out "Store", the setting will become invalid. For "End" operation, see Page 81.

Table 7.3 Initial setting value of the engineering mode

| Setting items | Initial set | Remarks |
|--|--|-----------------|
| ★Alarm hysteresis | ON(0.5%) | |
| ★Burnout (all channels) | OFF | |
| ★Channel offset (all channels) | 0.0 | |
| ★RJC (all channels) | Internal compensation INT | |
| ★Dot print color (1 to 6channel) | Purple(1), Red(2), Green(3), Blue(4), Brown(5), Black(6) | |
| ★REC record RUN/STOP trigger Channel/Tag print Alarm print Logging print Logging printing interval Logging print reference time Logging print scale print Logging print Sync/Async | INT Ch OFF ON 6H 00:00 OFF Sync (Synchronous) | Use the REC key |
| ★COM (communication) Address Data transfer rate Data length Parity bit Stop bit | 01 9600 8bit None 1bit | |
| ★DI function (1 to 3 channel) | OFF | |
| ★Temperature unit | ℃ | |

7.2.1 Alarm Hysteresis

Setting 0.5 % hysteresis to the values at alarm activation and alarm recovery is possible. (Common to all the alarms)

Example) Turning off alarm hysteresis.

| Display | Operation keys | Description |
|--------------|----------------|---|
| ALARM | | Enters the engineering mode (See the key operation in page 67). Use the Δ key to display "ALARM", and press the "ENT" key. |
| OFF | | Use the Δ key to display "OFF", and press the "ENT" key. |

7.2.2 Burnout ON/OFF

Setting Burnout High (to deflect the recording over the span) for each channel is possible.

Example) Setting Burnout High for Channel 4.

| Display | Operation keys | Description |
|-------------|----------------|--|
| bout | | Enters the engineering mode (See the key operation in page 67). Use the Δ key to display "bout", and press the "ENT" key. |
| CH4 | | Use the Δ key to display "CH4", and press the "ENT" key. |
| on | | Use the Δ key to select "on", and press the "ENT" key. |

7.2.3 Channel Offset

For channel offset setting, set the value to be added to an actual process variable.

Input value [-19999 to 99999]

Example) Setting the value (3.0) to be added to Channel 3.

| Display | Operation keys | Description |
|---------------|----------------|---|
| offset | | Enters the engineering mode (See the key operation in page 67). Use the Δ key to display "offset", and press the "ENT" key. |
| CH3 | | Use the Δ key to select "CH3", and press the "ENT" key. |
| 30000 | | Use the Δ key to alter a sign/numerical value or shift a decimal point. Use the \triangleright key to shift a digit. Once the numerical value is decided, press the "ENT" key. |

7.2.4 Reference Junction Compensation





















The following describes how to set the method for compensating an electromotive force generated between a thermocouple wire or compensation lead wire and a terminal. There are following 3 compensating methods:

- A method of compensation by the built-in temperature sensing element (INT: Internal compensation)
- A method of compensation by keeping an external compensator's temperature constant (EXT: External compensation)
- A method of compensation by one input for the recorder temperature which gets external junction box. (CH: Channel input compensation)
























Internal compensation (INT) has been initially set.

Example) Setting the external compensator's temperature constant voltage for Channel 6 to

391 μV . Input the thermocouple T, compensate the external compensator's temperature 10°C and Input the electromotive force 391 μV .

| Display | Operation keys | Description |
|---|--|--|
|   |    | Enters the engineering mode (See the key operation in page 67). Use the Δ key to display "r JE", and press the "ENT" key |
|   |   | Use the Δ key to select "CH6", and press the "ENT" key. |
|   |   | Use the Δ key to select "E 10", and press the "ENT" key. |
|   |    | Use the Δ key to alter a numerical value, or the \triangleright key to shift a digit. Once the numerical value is decided, press the "ENT" key. |
|   | | Setting is completed. Returned to the channel setting. |























Example) When Channel 1 input compensates Channel 6 reference junction.

| Display | Operation keys | Description |
|---|---|---|
|   |     | Enters the engineering mode (See the key operation in page 67). Use the Δ key to display "rJC", and press the "ENT" key. |
|   |    | Use the Δ key to select "CH6", and press the "ENT" key. |
|   |    | Use the Δ key to select "CH", and press the "ENT" key. |
|   |    | Use the Δ key to select "CH1", and press the "ENT" key. |
|   | | Setting is completed. Returns to the channel setting. |

7.2.5 Changing the Printing Color

A printing color can be changed for each channel.

Example) Setting the black color as a printing color.

| Display | Operation keys | Description |
|---|---|---|
|   |     | Enters the engineering mode (See the key operation in page 67). Use the Δ key to display "Color", and press the "ENT" key. |
|   |    | Use the Δ key to select "CH1", and press the "ENT" key. |
|   |    | Use the Δ key to display "ble", and press the "ENT" key. |
|   |     | Setting is completed. Returns to the Printing Color Setting screen. |























7.2.6 Settings Related to Recording

Setting a recording start/stop trigger, selecting tag/channel print, alarm print, logging print, and scale print ON/OFF are possible.

(1) Trigger setting for recording start/stop

Sets whether the trigger of recording start/stop should be "REC" key or DI.

Example) Setting DI as the recording start/stop trigger.

| Display | Operation keys | Description |
|---|---|---|
|   |     | Enters the engineering mode (See the key operation in page 67). Use the Δ key to display "rUn", and press the "ENT" key. |
|   |    | Use the Δ key to select "rUnEG", and press the "ENT" key. |
|   |    | Use the Δ key to display "E1E", and press the "ENT" key. |
|   |     | Setting is completed. Returns to the Recording Start/Stop Setting screen. |



















[Note]

When "E1E" is displayed, "RUN/STOP" key does not function. Set "rCd" to DI.
See DI functions in page 77.

(2) Tag/channel print selection

In the case of logging print; or manual print, this sets whether a tag or channel should be printed.

Example) Setting the tag.
















| Display | Operation keys | Description |
|---|---|---|
|   |     | Enters the engineering mode (See the key operation in page 67). Use the Δ key to display "rUn", and press the "ENT" key. |
|   |    | Use the Δ key to select "tAG", and press the "ENT" key. |
|   |    | Use the Δ key to display "tAG", and press the "ENT" key. |
|   | | Setting is completed. Returns to the Tag/Channel Setting screen. |

(3) Alarm print ON/OFF

Sets the alarm print ON/OFF.

When ON1, prints the alarm occurring and the alarm recovering. When ON2, prints only the alarm occurring.

Example) When sets both the alarm occurring and the alarm recovering.

























| Display | Operation keys | Description |
|---|--|---|
|   |    | Enters the engineering mode (See the key operation in page 67). Use the Δ key to display "rUn", and press the "ENT" key. |
|   |   | Use the Δ key to select "ALArA", and press the "ENT" key. |
|   |   | Use the Δ key to display "on 1", and press the "ENT" key. |
|   | | Setting is completed. Returns to the Alarm Print Setting screen. |

(4) Logging print ON/OFF

Sets logging print to ON/OFF.

In the case of logging print ON, this sets the print start time and print interval.












Example) When you want logging print to start at 18:00 every day.

| Display | Operation keys | Description |
|---|--|---|
|   |    | Enters the engineering mode (See the key operation in page 67). Use the Δ key to display "rUn", and press the "ENT" key. |
|   |   | Use the Δ key to select "dOePr", and press the "ENT" key. |
|   |   | Use the Δ key to display "on", and press the "ENT" key. |
|   (Print Start Time) |    | Use the Δ key to alter a numeral, and \triangleright key to shift a digit. Then, set the time and press the "ENT" key. |
|   (Interval) |   | Use the Δ key to display "24H", and press the "ENT" key. (Select from 10 min, 15 min, 20 min, 30 min, 1H, 2H, 3H, 4H, 6H, 8H, 12H and 24H) |
|   | | Setting is completed. Returns to the Logging print Setting screen. |

(5) Scale print ON/OFF

Set scale print to ON/OFF.












Example) Setting scale prints to OFF.

| Display | Operation keys | Description |
|---|--|---|
|  |    | Enters the engineering mode (See the key operation in page 67). Use the Δ key to display "run", and press the "ENT" key. |
|  |   | Use the Δ key to select "SCALE", and press the "ENT" key. |
|  |   | Use the Δ key to display "OFF", and press the "ENT" key. |
|  | | Setting is completed. Returns to the Scale Print Setting screen. |

(6) Logging print Synchronous/Asynchronous

Sets logging print to synchronous print/asynchronous.


































Example) Setting logging print to asynchronous.

| Display | Operation keys | Description |
|---|--|---|
|  |    | Enters the engineering mode (See the key operation in page 67). Use the Δ key to display "run", and press the "ENT" key. |
|  |   | Use the Δ key to select "d.SYNC", and press the "ENT" key. |
|  |   | Use the Δ key to display "ASync", and press the "ENT" key. |
|  | | Setting is completed. Returns to the logging print Sync/Async Setting screen. |

7.2.7 Setting the Communication Function

Sets Local Address, Data transfer rate (communication speed), Data Length, Parity Bit, and Stop Bit.

Example) Local Address: 02, Data transfer rate: 1200bps, Data Length: 7 bit, Parity Bit: even, Stop Bit: 2 bit.














| Display | Operation keys | Description |
|---|---|---|
|   |     | Enters the engineering mode (See the key operation in page 67). Use the Δ key to display "CoA", and press the "ENT" key. |
|   |    | Use the Δ key to display "Ad-02", and press the "ENT" key. (Select from Ad-0 1 to Ad-3 2) |
|   |    | Use the Δ key to display "1200", and press the "ENT" key. (Select from 1200, 2400, 4800, 9600) |
|   |    | Use the Δ key to display "7bit", and press the "ENT" key. (Select 7 bit or 8 bit) |
|   |    | Use the Δ key to display "EVEN", and press the "ENT" key. (Select from EVEN, ODD and NONE) |
|   |    | Use the Δ key to display "2bit", and press the "ENT" key. (Select 1 bit or 2 bit) |
|   | | Setting is completed. Returns to the Communication Function Setting screen. |

7.2.8 Initializing the Setup Data

Initializes the setup data to the status when it was shipped.

Be careful, because all the setup data is initialized. Calibration data is not initialized.

Example) Initializing you initialize the Setup Data.
















| Display | Operation keys | Description |
|---|---|---|
|   |     | Enter the engineering mode (See the key operation in page 67). Use the Δ key to display "Init", and press the "ENT" key. |
|   |    | Use the Δ key to select "YES", and press the "ENT" key. |
|   | | Initialization is completed. |

7.2.9 DI Functions

Allocates the functions to 3 DIs. There are following 12 DI functions.

| | |
|-------------------------------|--|
| No function | : OFF |
| Manual print (Sync.) | : $\overline{A}A\overline{A}-P$ (Positive edge: running start) |
| Manual Print (Async.) | : $\overline{A}A\overline{A}\overline{A}P$ (Positive edge: running start) |
| RUN/STOP trigger function | : \overline{rCd} (ON:RUN, OFF:STOP) |
| Date/Time Print (Sync.) | : $\overline{b}i\overline{A}-P$ (Positive edge: running start) |
| Date/Time Print (Async.) | : $\overline{A}b\overline{i}\overline{A}P$ (Positive edge: running start) |
| Chart feed speed selection | : \overline{SPEED} (ON:Spd-1, OFF:Spd-2) |
| Comment print 1 to 3 (Sync.) | : $\overline{C}\overline{A}\overline{n}\overline{b}1, \overline{C}\overline{A}\overline{n}\overline{b}2, \overline{C}\overline{A}\overline{n}\overline{b}3$ (Positive edge: running start) |
| Comment print 1 to 3 (Async.) | : $\overline{A}\overline{C}\overline{A}\overline{n}\overline{b}1, \overline{A}\overline{C}\overline{A}\overline{n}\overline{b}2, \overline{A}\overline{C}\overline{A}\overline{n}\overline{b}3$ (Positive edge: running start) |

Example) Setting comment prints 3 for DI3.

| Display | Operation keys | Description |
|---|---|---|
|  |  | Enters the engineering mode (See the key operation in page 67). Use the Δ key to display |
|  |   | "  ", and press the "ENT" key. |
|  |   | Use the Δ key to select "  ", and press the "ENT" key. |
|  |   | Use the Δ key to display "  ", and press the "ENT" key. |
|  | | Setting is completed. Returns to the DI3 Function Setting screen. |












[Note]

- DI synchronous does not print in STOP status, but DI asynchronous prints in STOP status.
- Be sure to set OFF when DI function (Option: RE6) is not designated.

7.2.10 Temperature Unit selection

Changes the setting of a temperature unit.

Example) Setting a temperature unit to Fahrenheit.

| Display | Operation keys | Description |
|---|---|--|
|  |  | Enters the engineering mode (See the key operation in page 67). Use the Δ key to indicate |
|  |   | "  ", and press the "ENT" key. |
|  |   | Use the Δ key to select "  ", and press the "ENT" key. |
|  | | Setting is completed. Returns to the Temperature Unit Setting screen. |

7.2.11 Point Calibration

Calibrates a dot printing position.

Zero: Calibration of the zero point position

FULL: Calibration of the span point position

[Note]

Point calibration "HYS" and "Color" are setup item before shipment. Do not change the setup value.

Example) Calibrating the zero point.

| Display | Operation keys | Description |
|---------|----------------|---|
| | | Enters the engineering mode (See the key operation in page 67). Use the Δ key to display "P Adj", and press the "ENT" key. |
| | | |
| | | Use the Δ key to select "Zero", and press the "ENT" key. |
| | | |
| | | The instrument starts to feed and print the chart paper. With the Δ (left move) and \triangleright (right move), adjust the 0 mm position of the chart paper and the recording position. Press the "ENT" key. Display indicates the set counter value. |
| | | Setting is completed. Returns to the Zero Point Calibration screen. |

Example) Calibrating the span point.

| Display | Operation keys | Description |
|---------|----------------|---|
| | | Enters the engineering mode (See the key operation in page 67). Use the Δ key to display "P Adj", and press the "ENT" key. |
| | | |
| | | Use the Δ key to select "FULL", and press the "ENT" key. |
| | | |
| | | The instrument starts to feed and print the chart paper. With the Δ (left move) and \triangleright (right move), adjust the 100 mm position of the chart paper and the recording position. Press the "ENT" key. Display indicates the set counter value. |
| | | Setting is completed. Returns to the Span Point Calibration screen. |

7.2.12 Data Calibration













































Calibrates the voltage, resistance temperature detector, and reference junction compensation.

VOLT : Calibration of the voltage

RTD : Calibration of the resistance temperature detector

RJC : Calibration of reference junction compensation



























Example) Calibrating the voltage at Channel 1.

| Display | Operation keys | Description |
|---|--|---|
|   |    | Enters the engineering mode (See the key operation in page 67). Use the Δ key to display "d Adj", and press the "ENT" key. Use the Δ key to select "VOLT", and press the "ENT" key. |
|   |   | Selects the channel where an instrument for calibration such as a mV generator is connected, and then, press the "ENT" key. |
|   |   | |
|   |  | Enter 0 mV. After 30 seconds, make sure that the ALM lamp is unlit and press the "ENT" key. |
|   |  | Enter 15 mV. After 10 seconds, make sure that the ALM lamp is unlit and press the "ENT" key. |
|   |  | Enter 25 mV. After 10 seconds, make sure that the ALM lamp is unlit and press the "ENT" key. |
|   |  | Enter 35 mV. After 10 seconds, make sure that the ALM lamp is unlit and press the "ENT" key. |
|   |  | Enter 55 mV. After 10 seconds, make sure that the ALM lamp is unlit and press the "ENT" key. |
|   |  | Enter 200 mV. After 10 seconds, make sure that the ALM lamp is unlit and press the "ENT" key. |
|   |  | Enter 1 V. After 10 seconds, make sure that the ALM lamp is unlit and press the "ENT" key. |
|   |  | Enter 5 V. After 10 seconds, make sure that the ALM lamp is unlit and press the "ENT" key. |
|   |  | Enter 10 V. After 10 seconds, make sure that the ALM lamp is unlit and press the "ENT" key. |
|   |   | If the calibration is correct, select "Store" with the Δ key, and if incorrect, select "Abort", respectively. Then, press the "ENT" key. |

[Note]

For calibration of voltage input, only one channel calibration is effective to all the channel.

Example) When calibrating the resistance temperature detector at Channel 2.

| Display | Operation keys | Description |
|---|--|--|
|   |    | Enters the engineering mode (See the key operation in page 67). Use the Δ key to display "d Adj", and press the "ENT" key. Use the Δ key to select "rEd", and press the "ENT" key. Select the channel where the instrument for calibration such as dial resistor is connected and then, press the "ENT" key. |
|   |   | |
|   |   | |
|   |  | Enter 100 Ω . After 10 seconds, make sure that the ALM lamp is unlit and press the "ENT" key. |
|   |  | Enter 150 Ω . After 10 seconds, make sure that the ALM lamp is unlit and press the "ENT" key. |
|   |  | Enter 300 Ω . After 10 seconds, make sure that the ALM lamp is unlit and press the "ENT" key. |
|   |   | If the calibration is correct, select "Store" with the Δ key, and if incorrect, select "Abort", respectively. Then, press the "ENT" key. |

[Note]


When calibrating RTD for a channel, short-circuit the other channels. Recording requires RTD calibration for every channel.

[Note]

During calibration, ALM lamp displays following conditions below.


①When the ALM lamp is unlit


The calibration is within the range.




②When the ALM lamp is blinking

Assessing the input value.




 : The lamp is unlit.


























 : The lamp is lit.

③When the ALM lamp is lit

The calibration is not within the range.
Make sure that the connection is proper and input is correct.



Example) Setting the terminal temperature for Channel 1.








| Display | Operation keys | Description |
|---|--|--|
|   |    | Enters the engineering mode (See the key operation in page 67). Use the Δ key to display "d Adj", and press the "ENT" key. |
|   |   | Use the Δ key to select "r JC", and press the "ENT" key. |
|   |   | Select the Channel to set, and press the "ENT" key. |
|   |  | Measures and displays the current terminal temperature. Press the "ENT" key, and the display turns to temperature setting. |
|   |    | Use the Δ key to alter a numeral, and \triangleright key to shift a digit. Then, press the "ENT" key. See 9.5 (3) Calibration of Reference Junction Compensation. |
|   |   | If the calibration is correct, select "Store" with the Δ key, and if incorrect, select "Abort", respectively. Then, press the "ENT" key. |

[Note]

When calibrating the terminal temperature, select a channel to calibrate for channel 1 to channel 3, and select another channel for channel 4 to channel 6. Calibrate these channels separately.

7.3 Terminating the Engineering Mode

Example) The following figure describes how to save the setting data.

| Display | Operation keys | Description |
|---|---|---|
|   |   | Use the Δ key to display "End", and press the "ENT" key. |
|   |  | Use the Δ key to select "Store", and press the "ENT" key. The settings of the engineering mode have been saved. Recording starts under the new settings. |

[Note]

When terminating the Engineering mode, if you select "End" and turn off the power without selecting "Store", the settings will become invalid. Selecting "Abort" invalidates the settings and starts recording under the previous settings.

8. COMMUNICATION

8.1 General Description

8.1.1 General Description of Functions

This Recorder has the following communication functions:

① Outputting the process variable

Process variable, alarms status, etc.

② Outputting the setting value

Reading the setup data such as a range, chart feed speed, etc.

③ Inputting the setting value

Writing the setup data such as a range, chart feed speed, etc.

④ Controlling of the recorder (Partially)

Selection to print, recording start/stop and changing display etc.

For the functions ② to ④, see the separate volume Communication Command Reference Manual (sold separately). Setting the engineering mode is not possible as for communication.

8.1.2 Transmission Specifications

| | |
|--------------------------|---|
| (1) Communication system | :Start-stop synchronous, half-duplex communications |
| (2) Connection | :One-to-one(RS-232C), One-to-N(RS-485); N = 1 to 32 |
| (3) Communication speed | :1200, 2400, 4800, or 9600 bps |
| (4) Start bit | :1 bit |
| (5) Stop bit | :1 or 2 bits |
| (6) Parity | :Even, Odd, or None |
| (7) Data length | :7 or 8 bits |

8.1.3 Data structure


(1) Character structre

In order to send 1data (byte) in start-stop synchronous communication, characters structure is as follows.

Start Bit (1) + Data Bit (7 or 8) + Parity Bit (1) + Stop Bit (1 or 2)

(2) Data format

The communication data is sent with data terminators added to multiple characters. On receiving these terminators, the recorder starts analyzing the communication data.



(3) Error Detection

If the recorder receives the data that has resulted in a signal error such as parity error, framing error, etc. due to the noise or hardware troubles, it will ignore that data. Consequently, a data format error results, determining that the data is not sent in the normal data format. The receiving function does not execute that command and the transmitting function does not reply. The data format error status can be confirmed by the ESC S command (described later).

(4) Control codes

ESC: 1B HEX (hexadecimal)

This code is used for an escape sequence such as opening/closing the link.

It cannot be treated as part of the text data.

CR: 0D HEX (hexadecimal)

This data is added to the end of the text data together with the LF data.

This code cannot be treated as part of the text data.

LF: 0A HEX (hexadecimal)

This data is added to the end of the text data together with the CR data.

This code cannot be treated as part of the text data.

8.2 Opening/Closing the Link

To communicate with the recorder, you must establish a connection between the host computer and the recorder. In the case of one-to-N communications, it is necessary to inform each recorder to which recorder the text is being sent. If a link open command is sent to multiple recorders through their send function, all the recorders, which have received the command, will send and cannot receive the normal data.

8.2.1 Open Command

(ESC)O_01(CR)(LF)

Address (01 to 32)

Space (20 Hex.)

To communicate the recorder, host computer must issue this command and memorize that it has issued this command.

8.2.2 Close Command

(ESC)C_01(CR)(LF)

Address (01 to 32)

Space (20Hex.)

If it is required that the data is sent to the recorders other than the open command is issued, this close command must be issued to those recorders open command was issued.

8.3 Outputting the Process Variable

8.3.1 Specifying the Process Variable Output

`TS 0(CR) (LF)`

Once this command is received, the recorder transfers the process variable to the transmission buffer, when the (ESC) T command is received.

8.3.2 Updating the Data

`(ESC) T(CR) (LF)`

Once this command is received, the recorder transfers the update process variable to the transmission buffer.

8.3.3 Specifying the Process Variable Output Order (At BINARY Mode Output)

`BO 0(CR) (LF)` Outputs start from the upper byte.

`BO 1(CR) (LF)` Outputs start from the lower byte.

The recorder outputs starting from the lower byte, unless specified.

8.3.4 Outputting the Data

`FM 0, S__CH, E__CH` Specifies the ASCII mode output.

`FM 1, S__CH, E__CH` Specifies the BINARY mode output.

S__CH :Output start channel 01 to 06

E__CH :Output end channel 01 to 06

※ When the number of channel is 1, specify (S__CH) = (E__CH).

8.3.5 Process Variable Transmission Format (ASCII)

DATE(YY)(MM)(DD)(CR)(LF) Date
Year Month Day

TIME(HH)(MM)(SS)(CR)(LF) Time
Hour Minute Second

(DS 1)(DS 2)(ALM 1)(ALM 2)(ALM 3)(ALM 4)(UNIT 1 to 6)(CHNo.), (DATA)(CR)(LF)

(1) DS 1 :Data information 1 (1 byte)

N : Normal
D : Difference computation data
S : Sum computation data
M : Average computation data
R : Square root computation data
C : Decade computation data
S : Skip (All the data is space)

(2) DS2 : Data information 2 (1 byte)

E : Final data
__(Space) : Other data

(3) ALM 1 to 4 : Alarm information (1 byte each, 4 bytes in total)

H : High limit alarm
L : Low limit alarm
__(Space) : Alarm OFF or alarm setting OFF.

(4) UNIT 1 to 6 :UNIT(6 bytes)

Returns the setting unit in terms of code. (When sending the 7-bit data, the higher 1 bit is missing.)

(5) CHNo. : Channel number (2 bytes)

01~06

(6) DATA :Process variable

Sign(1 byte) :“+” or “—”

Data mantissa section (6 bytes) :00000 to 99999

Data exponent section (4 bytes) : E (Sign: 1 byte) (Multiplier: 2 bytes)

<Example> +99999E-02

8.3.6 Process Variable Transmission Format (BINARY)

| | | | |
|--------------|---------------|--------------------|--------------------|
| Output bytes | Date and time | Process variable 1 | Process variable 6 |
|--------------|---------------|--------------------|--------------------|

Output bytes (2 bytes) : $5 \times n$ (specified number of channels)+6

(1) Date and time (6 bytes):

| | | | | | |
|---|---|---|---|---|---|
| ① | ② | ③ | ④ | ⑤ | ⑥ |
|---|---|---|---|---|---|

- ① Year : 00H to 63H (00H for the year 2000)
- ② Mouth : 01H to 0CH
- ③ Day : 01H to 1FH
- ④ Hour : 00H to 17H (24-hour system)
- ⑤ Minute: 00H to 3BH
- ⑥ Second: 00H to 3BH

(2) Process variable (5 bytes):

| | | | | | | |
|-------|----|----|----|----|-------|-------|
| CHNo. | A2 | A1 | A4 | A3 | DATA1 | DATA2 |
|-------|----|----|----|----|-------|-------|

CHNo.(1BYTE) : Channel number 01H to 06H


A1 to A4 (2BYTES) : Alarm type activated at each alarm level.

1 : High limit alarm

2 : Low limit alarm

0 : Alarm OFF or alarm setting OFF

Example) Bit Sequence.



LEVEL × H : High limit alarm bit at the alarm level x

LEVEL × L : Low limit alarm bit at the alarm level x

DATA1, DATA2 (2BYTES) : Process variable

— 32000 to +32000 (2-byte hexadecimal data)

The higher and lower bytes can be reversed by the BO command.

If Skip is specified, 8080H will be output.

[Note]

- Outputs a data over -32000 to +32000 as the overflow. An overflow 7E7E is output on plus side, and 8181 is output on minus side. (Excluding the Decade channel.)
- Data output of the Decade channel is as follows regardless of the BO command. The upper byte outputs a mantissa (10 to 99). The lower byte outputs an exponent (-19 to 19). A decimal point position is fixed on 1 digit.

8.4 Outputting the Unit and Decimal Point Position Data

8.4.1 Specifying the Unit and Decimal Point Position Data Output

TS2(CR)(LF)

Once this command is received, the recorder transfers the unit and decimal point position data to the transmission buffer, when the (ESC) T command is received.

8.4.2 Updating the Data

(ESC)T(CR)(LF)

Once this command is received, the recorder transfers the update unit and decimal point position data to the transmission buffer.

8.4.3 Outputting the Data

LF, S__CH, E__CH

S__CH :Output start channel 01 to 06

E__CH :Output end channel 01 to 06

※ When the number of channel is 1, specify (S_CH) = (E_CH). __ (Space)

8.4.4 Data Format

(DS 1) (DS 2) (CHNo.) (UNIT 1~6) (DP)

(1) DS 1 : Data information 1 (1 byte)

N : Normal

D : Difference computation data

S : Sum computation data

M : Average computation data

R : Square root computation data

C : Decade computation data,

S : Skip (All the data is space)

(2) DS 2 : Data information 2 (1 byte)

E :Final data,

__ (Space) :Other data

(3) CHNo. :Channel number (2bytes) ; 01 to 06

(4) UNIT 1 to 6 :UNIT

Returns the setting unit in terms of code. (When sending the 7-bit data, the higher 1 bit is missing.)

(5) DP :Decimal point information (1 byte) ; 0 to 4

[Note]

By the range setting, a decimal point position may differ from the one on a display screen.

8.5 Outputting the Status

If the open-link recorder has a data error on its link, it will save the error as a communication error in the internal status area. The (ESC S) command reads this status. Issuing this command, the on-going error is cleared.

8.5.1 Status Output Command

| |
|---------------|
| ESC S(CR)(LF) |
|---------------|

Receiving this command outputs the status for the command received so far.

8.5.2 Status Output

| | | | | | |
|---|---|---|---|----|----|
| E | R | X | X | CR | LF |
|---|---|---|---|----|----|

XX : 00 to 19

Table 8.1 Status output list

| Status factor Status output | Status factor | | |
|-------------------------------------|---------------|--------------|----------------------------|
| | A/D END | Syntax error | Running out of chart paper |
| ER 00 C _R L _F | | | |
| ER 01 C _R L _F | ○ | | |
| ER 02 C _R L _F | | ○ | |
| ER 03 C _R L _F | ○ | ○ | |
| ER 04 C _R L _F | | | |
| ER 05 C _R L _F | ○ | | |
| ER 16 C _R L _F | | | ○ |
| ER 17 C _R L _F | ○ | | ○ |
| ER 18 C _R L _F | | ○ | ○ |
| ER 19 C _R L _F | ○ | ○ | ○ |

○ : The factor from which status is ENABLE.


A/D END : When carrying out AD conversion ends, it occurs.

Syntax error : It occurs during a communication error or a command error.

Running out of chart paper : When Running out of chart paper is found, it occurs.

(When running out of chart paper option has been attached.)

8.6 Data Reception Example



9. MAINTENANCE

Inspect the following items in order to use this instrument effectively.

- Inspection
- Cleaning
- Replacing Consumables for the new one
- Adjustment of the Dot Printing Position
- Calibration

9.1 Inspection

Inspect the condition of operation periodically to use it effectively.

When a defect is found, see Chapter 10 “Troubleshooting”.

- ◆ Is trend recording deflected?
- ◆ Is recording indication done properly?
 - Are there any big errors in indicated values or dot printing position?
 - Is there improper dot printing?
 - Are there any blurred dot printing or printout?
 - Is printout proper?
- ◆ Is the chart paper fed properly?
 - Is the chart paper folded properly?
 - Aren't the feed holes in the chart paper torn off or broken?
 - Is the chart speed normal?
- ◆ Is there any abnormal sound?

9.2 Cleaning

Many parts of this instrument are made of plastic. Use a dry cloth to wipe the parts to keep them clean.

[Note]

Do not use any organic solvent.

9.3 Replacing Consumables

In order to use this instrument effectively, replace the consumable parts following the table.

| No. | Name | Type | Period | Remarks | Quantity |
|-----|-----------------|-----------------|---------|---------------------------------|----------|
| 1 | Chart paper | H-10100 | 33 days | When chart feed speed is 20mm/h | 1 |
| 2 | Ribbon cassette | WPSR188A000001A | 3months | When chart feed speed is 20mm/h | 1 |

[Note]

- ① When recording with a ribbon, a dot printing color phases out. To ensure clear recording, replace the ribbon cassette as soon as possible.
- ② Use the ribbon cassette within one year after its purchase. Due to evaporation of ink, a printing color phases out as time goes on.

9.4 Adjust Dot Printing Position (Point Calibration)

The following describes how to adjust a printing position on the chart paper.

You are well advised to adjust it annually in order to keep recording accurate.

How to Adjust

It is unnecessary to enter the reference. Leave the recorder as it is and adjust it according to the instructions in 7.2.11 Point Calibration.(See page 78)

9.5 Calibration (Data Calibration)

Calibrate a process variable input annually in order to keep measurement accurate.

[Note]


Prior to calibration, warm up for 30 minutes or more after power-on.

Devices required for calibration

- Precision voltage(current) generator (Jointly use a digital voltmeter with accuracy of $\pm 0.02\%$ or less as required)
- Precision dial resistor

(1) Calibration of Voltage

Conduct calibration in the case of voltage, current or thermocouple input. For thermocouple input, calibrate reference junction compensation together.




Calibrate the voltage according to the instructions in 7.2.12 Data Calibration (Calibration of the voltage). (See page 79)

[Note]

- ① Calibrate at any one channel.
- ② When a shunt resistor is attached to the input terminal block in the case of current input, detach it prior to calibration.

(2) Calibration of Resistance temperature detector (RTD)




Calibrate RTD according to the instructions in 7.2.12 Data Calibration (Calibration of the resistance temperature detector). (See page 80)

[Note]

The dispersion of resistance value for each wire must be 6 m Ω or less.
Calibrate RTD in all channels.
Short-circuit the input terminals except calibration channel.

(3) Calibration of Reference Junction Compensation

Calibrate the reference junction compensation in the case of thermocouple input.



Example) Connect the input to Channel 1 and set the calibration when the thermocouple input value (RMC measurement) is -0.5 (input 0°C), the measured RJC temperature is 24.5°C.

- 1) Check the Process variable when impressing 0.000mV±2 μV to Channel 1 by the voltage generator beforehand. (In this example, it is -0.5°C.)
- 2) Check the terminal temperature of Channel 1 at the data calibration in the engineering mode (Reference junction compensation). (In this example, it is 24.5°C.)
- 3) Set the value which is added the difference (0.5°C) with true value as the right RJC temperature.

$$[24.5 - (-0.5) = 25.0^{\circ}\text{C}]$$

Calibrate RJC according to the instructions in 7.2.12 Data Calibration (Calibration of reference junction compensation).(See page 81)


[Note]

- ① This calibration is conducted when compensation by the recorder's built-in temperature sensing element (INT: internal compensation) is selected as the reference junction compensation method.
- ② Wire to Channels 1 and 4 to calibrate.
- ③ After wiring, attach the terminal covers and wait for 5 minutes or more, then calibrate it.


10. TROUBLESHOOTING

10.1 Troubleshooting


10.1.1 Trouble Items




10.1.2 When the Recorder Dose not Work at All




10.1.3 When there is a Big Error




10.1.4 When the Trend Recording is Deflected




10.1.5 When nothing is recorded




10.1.6 When Recording is Faint



10.1.7 When the Chart Paper is not fed at All



10.1.8 When the Chart Paper is not fed Properly



10.2 Self Diagnosis Function (ERROR)

This instrument always diagnoses itself on the items listed in the Table 10.1 below. When an error is found in the self diagnosis results, a relevant error number is displayed.

10.2.1 Self diagnosis Items

Table 10.1 Status output list

| Type | Error message | Part | Diagnosis | Remedy |
|-----------------|---------------|---------------------------------|--|--|
| Hard ware error | E Err01 | Zero point sensor | Zero point position of servomotor cannot be detected. | Contact our dealer where you purchased the instrument or our sales representative. |
| | E Err02 | ADC | AD conversion end error, Initializing error | |
| | E Err03 | IC for clock | The clock battery is used up[Note1] | |
| | E Err04 | WDT | Watchdog timer error | |
| | E Err05 | EEP WRITE | Non-volatile memory Writing error | |
| | E Err06 | EEP READ1 | Non-volatile memory Reading error (Setup data) | |
| | E Err07 | EEP READ2 | Non-volatile memory Reading error (Engineering data) | |
| | E Err08 | EEP READ3 | Non-volatile memory Reading error (ADC Calibration data) | |
| Operation error | E Err21 | Area error | Input value is beyond the setting range. | Set properly |
| | E Err22 | Time error | Clock time setting error | |
| | E Err23 | Setting range error | Setting the channel (CH1) which cannot set the sum/difference/average operation. | |
| | E Err24 | Area error | Span L \geq Span R | |
| | E Err25 | Area error | Scale L \geq Scale R | |
| | E Err26 | Area error | Zone L \geq Zone R or Zone R – Zone L is less than 5mm. | |
| | E Err27 | Reference channel setting error | The reference channel range of the sum/difference/average operation is except Volt, TC, RTD and SCALE. | |
| | E Err28 | All channels skip error | Setting the all channels to Skip | |
| other | E Err41 | Calibration value input error | Not calibrating with the specified input. | Calibrate it with correct input. |

[Note1] The battery life is supposed to last approx.10 years but sometimes depends on the environment it is used.

10.2.2 Error Display

- When multiple errors occur, their serial error numbers are displayed automatically.
- When an error is recovered, an error display can be canceled by inputting the “REC” key.



CAUTION

While an error is indicated, Auto, Manual and Data/Time are not indicated.

11. SPECIFICATIONS

11.1 Common Specifications

11.1.1 Input Signal

DC voltage : ± 10 , 0 to 20, 0 to 50, ± 200 mV DC, ± 1 , 0 to 5, ± 10 V DC

Thermocouple : B, R, S, K, E, J, T, C, Au-Fe, N, PR40-20, PL II, U, L

Resistance temperature detector : Pt100, JPt100

DC current : 4 to 20mA_{dc} (External shunt resistor: 250 Ω <sold separately: HMSU3081A11>)

11.1.2 Performance and Characteristics

Digital accuracy rating : See 11.2.1

Input impedance : 10M Ω min. in mV, TC input (without burnout)

200k Ω min. in mV, TC input (with burnout)

1M Ω min. in voltage input

250 Ω shunt resistance : external <sold separately: HMSU3081A11>
in mA input

Allowable signal source resistance

: 10k Ω max. in mV, TC input (without burnout)

100 Ω max. in mV, TC input (with burnout)

1k Ω max. in Voltage input

10 Ω max.(per line) in Resistance temperature detector input

Normal mode reduction ratio : 60dB min.(50/60 \pm 0.1Hz)

Common mode reduction ratio : 140dB min.(50/60 \pm 0.1Hz)

Isolation resistance : 0.5kV_{dc} 20M Ω min. between each terminal and grounding terminal

Withstand Voltage : 1.5kV_{ac} for 1 minute between the power terminal and grounding terminal

: 0.5kV_{ac} for 1 minute between the input terminal and grounding terminal

: 0.2kV_{ac} for 1 minute between the input terminals

Interchannel maximum noise voltage: 200 Vac at 50/60 Hz

Vibration resistance : 10 to 60Hz 1m/s² max.

Shock resistance : 2m/s² max.

Clock precision : ± 50 ppm max.

Chart feed accuracy : $\pm 0.1\%$ max.

11.1.3 Structure

Mounting : Panel mounting(vertical panel)
Allowable backward inclination : Within 30°

Material(Color) : Case ; Polycarbonate(Black), Glass 10% UL94-V2
Door ; Polycarbonate UL94-V2(Clear)
; Dust-proof, drip-proof (Based on IEC529-IP65) not evaluated as part of Underwriters Laboratories Listing certification.

11.1.4 Power Source

Rated supply voltage range : 100 to 240Vac
Working supply voltage range : 85 to 264Vac
Rated power frequency : 50/60Hz
Working frequency range : 45 to 65Hz

Table 11.1 Power consumption

| | 100VAC | Max. power consumption |
|----------------|------------|------------------------|
| 6-dot recorder | About 25VA | About 30VA |

11.1.5 Normal Operating Conditions

Ambient temperature : 0 to 50°C
Ambient humidity : 20 to 80%RH
Supply voltage : 85 to 264Vac
Supply frequency : 45 to 65Hz
Vibration : 10 to 60Hz 0.2m/s² max.
Shock : Unacceptable
Magnetic field : 400A/m max. (DC and AC: 50/60Hz)
Noise : Normal mode(50/60Hz)
DC current, Thermocouple; Peak value lower than the span width of the measurement range
Resistance temperature detector ; 50mV max.
Common mode (50/60Hz) ; 250Vac max.
Interchannel maximum noise voltage: 200 Vac at 50/60 Hz

Posture : Allowable backward inclination : within 30°, Right-and-left level
Warming up time : 30 minutes min. from the time of a power-on

11.1.6 Alarm Output (Option : LH6)

| | |
|------------------------|---|
| Number of output | : 6 points (Built-in option, normally open) |
| Alarm type | : 2 types (H, L), total 4 levels/channel |
| Contact point capacity | : 250Vac, 3A max. (Resistive load) 30Vdc, 3A max. (Resistive load) 125Vdc, 0.5A max. (Resistive load) |
| Hysteresis | : 0.5% |
| Setting accuracy | : Digital display accuracy |

11.1.7 Safety Standard and EMI Standard

| | |
|-------------------|--|
| Electrical safety | : IEC1010-1, UL3101-1 Installation category II and pollution degree 2. |
| Emissions | : EN55011 Group1 Class A |
| Immunity | : EN50082-2 |

11.1.8 DI Function (Option : RE6)

A maximum of 3 points can be set.

11.1.9 Running out of paper Detecting Function (Option : FL)

Detects the Running out of paper and outputs it to an alarm.

11.2 Standard Specifications

11.2.1 Measurement Range

The arbitrary setup is possible by the front key operation.

A digital accuracy rating is as Table 11.1 at Reference operating conditions. It is shown below.

| | | |
|--------------------------------|-------------------------|-------------------|
| Reference operating conditions | Ambient temperature | ; 23 ±2°C |
| | Ambient humidity | ; 55 ±10%RH |
| | Power source voltage | ; 85 to 264Vac |
| | Electric wave frequency | ; 50/60Hz ±1% |
| | Warming up time | ; 30 minutes min. |

The performance in the state where there is no vibration and shock.

Terminal block reference junction compensation accuracy is not included in the digital indicating accuracy rating.

Terminal block reference junction compensation accuracy

◇B, R, S, Au-Fe, PR40-20 : ±1°C

◇K, E, J, T, C, N, PL II, U, L : ±0.5°C

Table 11.2 Measurement Range

| Type | RANGE | Measurement range | Measurement | | |
|-----------------------------|-------|-------------------|---|-----------------|---|
| | | | Indication (Digital) | | Recording (Analog) |
| | | | Accuracy | Max. resolution | Accuracy |
| DC voltage DC current input | | -10 to 10mV | ±(0.2% of rdg + 3digits) | 10 μ V | Digital display accuracy ±(0.3% of span) |
| | | 0 to 20mV | ±(0.2% of rdg + 3digits) | 10 μ V | |
| | | 0 to 50mV | ±(0.2% of rdg + 2digits) | 10 μ V | |
| | | -200 to 200mV | ±(0.2% of rdg + 3digits) | 100 μ V | |
| | | -1 to 1V | ±(0.1% of rdg + 3digits) | 1mV | |
| | | 0 to 5V | ±(0.2% of rdg + 2digits) | 1mV | |
| | | -10 to 10V | ±(0.3% of rdg + 3digits) | 10mV | |
| | | 4 to 20mA | ±(0.2% of rdg + 2digits) | 0.01mA | |
| Thermocouple | B | 0.0 to 1820.0°C | ±(0.15% of rdg + 1°C) 400 to 600°C, ±2°C An accuracy is not guaranteed within a range of 0 to less than 400°C | 0.1°C/0.18°F | Digital display accuracy ±(0.3% of span) |
| | | 32.0 to 3308.0°F | ±(0.15% of rdg + 1.8°F) 752 to 1112°F, ±3.6°F An accuracy is not guaranteed within a range of 32 to less than 752°F | | |
| | R1 | 0.0 to 1760.0°C | ±(0.15% of rdg + 1°C) ※0 to 100°C, ±3.7°C 100 to 300°C, ±1.5°C | | |
| | | 32.0 to 3200.0°F | ±(0.15% of rdg + 1.8°F) ※32 to 212°F, ±6.7°F 212 to 572°F, ±2.7°F | | |

| Type | RANGE | Measurement range | Measurement | | |
|--------------|-------|--------------------|--|-----------------|---|
| | | | Indication (Digital) | | Recording (Analog) |
| | | | Accuracy | Max. resolution | Accuracy |
| Thermocouple | R2 | 0.0 to 1200.0°C | ±(0.15% of rdg + 0.8°C) ※0 to 100°C, ±3.7°C 100 to 300°C, ±1.5°C | 0.1°C/0.18°F | Digital display accuracy ±(0.3% of span) |
| | | 32.0 to 2192.0°F | ±(0.15% of rdg + 1.44°F) ※32 to 212°F, ±6.7°F 212 to 572°F, ±2.7°F | | |
| | S | 0.0 to 1760.0°C | ±(0.15% of rdg + 1°C) ※0 to 100°C, ±3.7°C 100 to 300°C, ±1.5°C | | |
| | | 32.0 to 3200.0°F | ±(0.15% of rdg + 1.8°F) ※32 to 212°F, ±6.7°F 212 to 572°F, ±2.7°F | | |
| | K1 | -200.0 to 1370.0°C | ±(0.15% of rdg + 0.7°C) ※-200 to -100°C, ±(0.15% of rdg + 1°C) | | |
| | | -328.0 to 2498.0°F | ±(0.15% of rdg + 1.3°F) ※-328 to -148°F, ±(0.15% of rdg + 1.8°F) | | |
| | K2 | -200.0 to 600.0°C | ±(0.15% of rdg + 0.4°C) ※-200 to -100°C, ±(0.15% of rdg + 1°C) | | |
| | | -328.0 to 1112.0°F | ±(0.15% of rdg + 0.7°F) ※-328 to -148°F, ±(0.15% of rdg + 1.8°F) | | |
| | K3 | -200.0 to 300.0°C | ±(0.15% of rdg + 0.3°C) ※-200 to -100°C, ±(0.15% of rdg + 1°C) | | |
| | | -328.0 to 572.0°F | ±(0.15% of rdg + 0.5°F) ※-328 to -148°F, ±(0.15% of rdg + 1.8°F) | | |
| | E1 | -200.0 to 800.0°C | ±(0.15% of rdg + 0.5°C) | | |
| | | -328.0 to 1472.0°F | ±(0.15% of rdg + 0.9°F) | | |
| | E2 | -200.0 to 300.0°C | ±(0.15% of rdg + 0.4°C) | | |
| | | -328.0 to 572.0°F | ±(0.15% of rdg + 0.7°F) | | |
| | E3 | -200.0 to 150.0°C | ±(0.15% of rdg + 0.3°C) | | |
| | | -328.0 to 302.0°F | ±(0.15% of rdg + 0.5°F) | | |
| | J1 | -200.0 to 1100.0°C | ±(0.15% of rdg + 0.5°C) ※-200 to -100°C, ±(0.15% of rdg + 0.7°C) | | |
| | | -328.0 to 2012.0°F | ±(0.15% of rdg + 0.9°F) ※-328 to -148°F, ±(0.15% of rdg + 1.3°F) | | |
| | J2 | -200.0 to 400.0°C | ±(0.15% of rdg + 0.4°C) ※-200 to -100°C, ±(0.15% of rdg + 0.7°C) | | |
| | | -328.0 to 752.0°F | ±(0.15% of rdg + 0.7°F) ※-328 to -148°F, ±(0.15% of rdg + 1.3°F) | | |
| | J3 | -200.0 to 200.0°C | ±(0.15% of rdg + 0.3°C) ※-200 to -100°C, ±(0.15% of rdg + 0.7°C) | | |
| | | -328.0 to 392.0°F | ±(0.15% of rdg + 0.5°F) ※-328 to -148°F, ±(0.15% of rdg + 1.3°F) | | |

| Type | RANGE | Measurement range | Measurement | | |
|---------------------------------|-------------------|-------------------------|--|-----------------|---|
| | | | Indication (Digital) | | Recording (Analog) |
| | | | Accuracy | Max. resolution | Accuracy |
| Thermocouple | T1 | -200.0 to 400.0°C | ±(0.15% of rdg + 0.5°C) ※-200 to -100°C, ±(0.15% of rdg + 0.7°C) | 0.1°C/0.18°F | Digital display accuracy ±(0.3% of span) |
| | | -328.0 to 752.0°F | ±(0.15% of rdg + 0.9°F) ※-328 to -148°F, ±(0.15% of rdg + 1.3°F) | | |
| | T2 | -200.0 to 200.0°C | ±(0.15% of rdg + 0.4°C) ※-200 to -100°C, ±(0.15% of rdg + 0.7°C) | | |
| | | -328.0 to 392.0°F | ±(0.15% of rdg + 0.7°F) ※-328 to -148°F, ±(0.15% of rdg + 1.3°F) | | |
| | C | 0.0 to 2320.0°C | ±(0.15% of rdg + 1°C) | | |
| | | 32.0 to 4208.0°F | ±(0.15% of rdg + 1.8°F) | | |
| | Au-Fe | 1.0 to 300.0K | ±(0.15% of rdg + 1K) ※1 to 20 K, ±2.4 K | 0.1K | |
| | N | 0.0 to 1300.0°C | ±(0.15% of rdg + 0.7°C) | 0.1°C/0.18°F | |
| | | 32.0 to 2372.0°F | ±(0.15% of rdg + 1.3°F) | | |
| | PR40-20 | 0.0 to 1880.0°C | ±(0.15% of rdg + 1°C) ※0 to 300°C, ±37.6°C 300 to 800°C, ±18.8°C | | |
| | | 32.0 to 3416.0°F | ±(0.15% of rdg + 1.8°F) ※32 to 572°F, ±67.7°F 572 to 1472°F, ±33.8°F | | |
| | PL II | 0.0 to 1390.0°C | ±(0.15% of rdg + 0.7°C) | | |
| | | 32.0 to 2534.0°F | ±(0.15% of rdg + 1.3°F) | | |
| | U | -200.0 to 400.0°C | ±(0.15% of rdg + 0.5°C) ※-200 to -100°C, ±(0.15% of rdg + 0.7°C) | | |
| | | -328.0 to 752.0°F | ±(0.15% of rdg + 0.9°F) ※-328 to -148°F, ±(0.15% of rdg + 1.3°F) | | |
| | L | -200.0 to 900.0°C | ±(0.15% of rdg + 0.5°C) ※-200 to -100°C, ±(0.15% of rdg + 0.7°C) | | |
| | | -328.0 to 1652.0°F | ±(0.15% of rdg + 0.9°F) ※-328 to -148°F, ±(0.15% of rdg + 1.3°F) | | |
| Resistance temperature detector | Pt100-1 | -200.0 to 650.0°C | ±(0.15% of rdg + 0.3°C) | | |
| | | -328.0 to 1202.0°F | ±(0.15% of rdg + 0.6°F) | | |
| | Pt100-2 | -200.0 to 200.0°C | ±(0.15% of rdg + 0.2°C) | | |
| | | -328.0 to 392.0°F | ±(0.15% of rdg + 0.4°F) | | |
| | JPt100-1 | -200.0 to 630.0°C | ±(0.15% of rdg + 0.3°C) | | |
| | | -328.0 to 1166.0°F | ±(0.15% of rdg + 0.6°F) | | |
| JPt100-2 | -200.0 to 200.0°C | ±(0.15% of rdg + 0.2°C) | | | |
| | -328.0 to 392.0°F | ±(0.15% of rdg + 0.4°F) | | | |

B,R,S,K,E,J,T,N :JIS C 1602-1995(IEC584-1)
 C :Made by "Hoskins" (WRe5-26)
 Au-Fe :ASTM COMMITTEE-20 ON TEMPERATURE MEASUREMENT
 PR40-20 :ASTM E1751-1995
 PL II :ASTM E1751-1995
 U :DIN43710 :1985(Cu-CuNi)
 L :DIN43710 :1985(Fe-CuNi)
 Pt100 :JIS C 1604-1997(IEC751)
 JPt100 :(JIS C 1604-1981)

11.2.2 The Accuracy at the Computation

(1) Scaling

The accuracy rating at the scaling is shown as following formula.

$$\text{Scaling accuracy (digits)} = \pm(\text{Range accuracy rating (digits)} \times \text{Scaling factor} + 2 \text{ digits})$$

$$\text{But, Scaling factor} = \frac{\text{Scaling span (digits)}}{\text{Measurement range span (digits)}}$$

Example 1) When VOLT range is -1.000 to 1.000V and Scaling range is 0.00 to 100.00 .

$$\text{Range accuracy rating} = 0.1\% \times 1.000\text{V} + 3 \text{ digits}$$

$$(\text{Input } +1.000\text{V}) = 4 \text{ digits}$$

$$\text{Scaling factor} = \frac{10000 - 0}{1000 - (-1000)} = 5$$

$$\begin{aligned} \text{Therefore, Scaling accuracy} &= \pm(4 \times 5 + 2) \\ &= \pm 22 \text{ digits} \end{aligned}$$

$$\begin{aligned} \text{Analog recording accuracy} &= \pm \left[4 + \{1000 - (-1000)\} \times \frac{0.3}{100} \right] \\ &= \pm 10 \text{ digits} \\ &= \pm 0.01\text{V} \end{aligned}$$

Example 2) When Type K is 0.0 to 200.0°C and Scaling is 0.00 to 200.00 .

$$\text{Range accuracy rating} = 0.15\% \times 200.0 + 0.3^\circ\text{C}$$

$$(\text{Input } 200^\circ\text{C}) = 0.6^\circ\text{C}$$

$$= 6 \text{ digits}$$

$$\text{Scaling factor} = \frac{20000 - 0}{2000 - 0} = 10$$

$$\begin{aligned} \text{Therefore, Scaling accuracy} &= \pm(6 \times 10 + 2) \\ &= \pm 62 \text{ digits} \\ &= \pm 0.62^\circ\text{C} \end{aligned}$$

(2) Square root computation

The square root computation is shown as following formula.

$$\text{Display value} = 10 \sqrt{\text{Process variable}}$$

Display value accuracy rating: \mathcal{E} , Process variable accuracy: e , and
Process variable: x (convert into %).

$$\text{Display value} = 10 \sqrt{x \pm e} \doteq 10 \sqrt{x} \pm \frac{10e}{2\sqrt{x}}$$

$$\text{Therefore, Display value accuracy } \mathcal{E} = \frac{5e}{\sqrt{x}}$$

When input 4 to 20mA, the square root computation accuracy: ϵ is as following formula.

$$\begin{aligned} \text{Measuring 100\%} \quad \epsilon_{100} &= \frac{5e}{\sqrt{100}} = \frac{5(0.2+0.125)}{10} = 0.16\% \text{ rdg} \\ \text{Measuring 50\%} \quad \epsilon_{50} &= \frac{5e}{\sqrt{50}} = \frac{5(0.1+0.167)}{7.07} = 0.19\% \text{ rdg} \\ \text{Measuring 9\%} \quad \epsilon_9 &= \frac{5e}{\sqrt{9}} = \frac{5(0.018+1.39)}{3} = 2.3\% \text{ rdg} \\ \text{Measuring 1\%} \quad \epsilon_1 &= \frac{5e}{\sqrt{1}} = 5(0.002+12.5) = 62.5\% \text{ rdg} \end{aligned}$$

If the process variable is low as above, its accuracy rating is incorrect.

(3) Decade

The accuracy rating at the decade computation is defined the logarithm of display value. Normally, the accuracy rating is less than 1 digit and you cannot read by significant digit.

(4) Difference, Sum, and Average

The accuracy rating of Difference, Sum, and Average is shown as following formula.

Difference and Sum : Reference channel accuracy rating $\times 2$

Average : Reference channel accuracy rating

Example) When Reference channel VOLT is 00.00 to 10.00V and Difference is -10.00 to 10.00 .

$$\begin{aligned} \text{Reference channel accuracy rating} &= \pm (0.3\% \times 10.00V + 3 \text{ digits}) \\ &= \pm (1000 \times 0.003 + 3) \\ &= \pm 6 \text{ digits} \end{aligned}$$

$$\text{Difference accuracy rating} = \pm 6 \times 2 = \pm 12 \text{ digits}$$

11.2.3 Individual Specifications

Table 11.3 Specification Items

| Block | Item | Specification |
|-------------------|------------------|---|
| Input Unit | Measuring Point | 6 |
| | Input Sampling | 10s/6CH |
| | Display Interval | 2.5s |
| Record & Printer | Recording Form | Wire dot (6-color ink ribbon) |
| | Printing Form | |
| | Recording Width | 100mm |
| | Print Period | 10s/6CH [Note 1] |
| | Chart paper | Length : 16m, Width : 114mm, Folding width : 40mm The length of the Clean Chart is 12 m. |
| | Chart feed speed | 0, 1, 2, 3, 4, 5, 10, 15, 20, 25, 30, 40, 50, 60, 75, 80, 90, 100, 120, 150, 160, 180, 200, 240, 300, 360, 375, 450, 600, 720, 750, 900, 1200, 1500mm/h (Analog recording is not done during the chart feed speed is set to 0mm/h.) |
| | Recording color | No.1(Purple), No.2(Red), No.3(Green), No.4(Blue), No.5(Brown), No.6(Black) [Note 2] |
| | Printing color | Purple, Red, Green, Blue, Brown, Black |
| Weight | | 1.5kg max. |
| Power consumption | | 25VA max. (at 100Vac) |

[Note 1] Select the Dot Point Interval from 10, 20, 30 and 60 seconds depending on the setting.

[Note 2] Possible to the arbitrary color.

11.2.4 Standard Functions

Table 11.4 Standard Functions

| Item | Description |
|-----------------------------|---|
| Analog indication | None |
| Analog recording | Analog recording with 6-color dot. |
| Engineering unit indication | None |
| Digital display | Indicates Channel No., Process variable, Chart feed speed, Alarm setting value on the display. |
| Logging print | Prints Date, Time, Scaling, Chart feed speed, Process variable and Engineering unit at a programmed interval. With the setting, it is possible to choose. Synchronous Asynchronous print. |
| List print | Prints Chart feed speed, Sensor type, Measurement range, Engineering unit, Alarm setting value, Comment, Printing description, Logging print ON/OFF, Zone, Partial Compression/Expansion |
| Engineering list print | Prints Channel or Tag, Alarm function, Logging print ON/OFF, Reference time, Interval, Scaling print ON/OFF, Logging print Sync./Async., Alarm hysteresis, Burn out, DI function(Optional) |
| Affix print | Prints Channel number near the analog record. |
| Manual print | Prints Measurement result by key input. Analog recording pauses. |
| Dot print skip | Skips recording an unused channel. |
| Programming | Programs Chart feed speed, Alarm setting value, Logging, Dot point skip, Date and Time by key operation. |
| Memory back up | A built-in lithium battery protects the clock function. The battery life is 10 years. (total power off period of the instrument : 5 years) A non-volatile memory stores setting data and calibration data. |
| Alarm | Sets 2 types (H, L) of alarms per channel. Sets a total of 4 levels. |
| Chart feed speed | Selects Chart feed speed from 34 types. |
| Clock indication | Indicates Year, Month, Day, Hour and Minute. Sets the year in A.D, and adjusts leap year automatically. |
| Self diagnosis | When malfunctions occur "E Err * *" is indicated. (* *: type of the defect) |
| Scaling | Indicates and record the input of a unification signal 4 to 20mA etc. is converted into the engineering scales. |

11.3 Standard Setting Functions

11.3.1 Standard Setting Functions

Table 11.5 Standard Setting Functions

| Function | Description |
|----------------------------------|--|
| Burnout | To deflect over toward 100% with disconnecting input. Possible to specify the every channel's burnout. (DC voltage of $\pm 50\text{mV}$ max., TC input) |
| Tag Number setting | Sets a tag number up to 7 characters every channel. (Prints at a logging print) |
| Reference Junction Compensation | Specifies an inside/outside of the Reference Junction Compensation. |
| Copy Function | Copies a channel setting. |
| Setting input offset setting | Setting input offset is possible for each channel. |
| Zone Recording (Track Recording) | Specifies a recording area per channel to separate the record into Tracks. |
| Partial compression/expansion | Records Partial Compression/Expansion to 1-crease line every channel. |
| Decade Recording Indication | Records and indicates by 5 decades. It is 2 digits that the effective number to indicate and print. |
| Alarm Print | Prints Occurrence time, Occurrence channel, Setting No. and Alarm type in purple when alarm activates. |
| Alarm Recovery Print | Prints Recovery time, Recovery channel, Setting No. and Alarm type in purple when alarm recovers. |
| Computation | Computes Square root. |
| Interchannel Computation | Computes Sum, Difference and Average between channels. |
| Alarm Hysteresis Width | Sets an alarm hysteresis width 0% FS or 0.5% FS. |

11.4 Optional Functions

11.4.1 Remote Function by DI function

| Function | Description |
|------------------------------------|---|
| Chart Feed Start/Stop | Starts with turning to ON. Stops with turning to OFF. |
| Changing Chart feed Speed | Changes 1st with turning to ON and 2nd with OFF. |
| Comment Print (Sync./Async.) | Prints Comment with turning to ON. |
| Manual Print (Sync./Async.) | Prints Manual Print with turning to ON. |
| Date and Time Print (Sync./Async.) | Prints Date and Time with turning to ON. |

11.4.2 Alarm Output function

6 relays

11.4.3 Communication unit

RS-232C(Standard)

RS-485(Optional)

Shinko North America Ltd.

Office : 25 Whitefriars Drive Toronto, Ontario, Canada M3A 2L2
Mail Address : 25 Whitefriars Drive Toronto, Ontario, Canada M3A 2L2
URL : <http://www.shinkona.com> Tel : 416 444-0817
Toll Free: : 1 866-4SHINKO Fax: 416 444-2361

No.HR 7 1 E 3 2001.10